

# TABLE OF CONTENTS

---

|   |                |
|---|----------------|
| <b>ENGINE .....</b>                       | <b>03-02-1</b> |
| ENGINE LEAK VERIFICATION FLOW CHART ..... | 03-02-11       |

---

|                                  |                |
|----------------------------------|----------------|
| <b>FUEL AND OIL SYSTEMS.....</b> | <b>03-03-1</b> |
|----------------------------------|----------------|

---

|   |                |
|---|----------------|
| <b>TRANSMISSION AND BRAKE SYSTEMS .....</b> | <b>03-04-1</b> |
| <b>TRANSMISSION.....</b>                    | <b>03-04-1</b> |
| <b>BRAKE SYSTEM.....</b>                    | <b>03-04-7</b> |
| MECHANICAL BRAKE .....                      | 03-04-7        |
| HYDRAULIC BRAKE .....                       | 03-04-8        |
| MECHANICAL AND HYDRAULIC BRAKES.....        | 03-04-8        |

---

|                               |                |
|-------------------------------|----------------|
| <b>ELECTRICAL SYSTEM.....</b> | <b>03-05-1</b> |
|-------------------------------|----------------|

---

|                                   |                |
|-----------------------------------|----------------|
| <b>SUSPENSION AND TRACK .....</b> | <b>03-06-1</b> |
|-----------------------------------|----------------|

# ENGINE

The following chart is provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>ENGINE BACKFIRES.</b>  |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check spark plug(s).</b><br>a. Carbon accumulation caused by defective spark plug(s).<br><i>Clean carbon accumulation and replace spark plug(s).</i>  |
|                        | <b>2. Check cooling system.</b><br>a. Loose fan belt.<br><i>Adjust or replace fan belt (refer to TECHNICAL DATA 10).</i><br>b. Low antifreeze level.<br><i>Adjust antifreeze level. Then check clamps or hoses.</i><br>c. Defective tank cap.<br><i>Replace cap.</i><br>d. Air in system.<br><i>Bleed system.</i> |
|                        | <b>3. Check ignition timing.</b><br>a. Timing is too advanced.<br><i>Set timing according to specifications (refer to TECHNICAL DATA 10).</i>   |

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

| SYMPTOM         | ENGINE SUDDENLY TURNS OFF.   |
|-----------------|--|
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <b>1. Perform engine leak test. Refer to engine leak verification flow chart. Check possible piston seizure.</b><br>a. Damaged gasket and/or seal.<br><i>Replace defective parts.</i>  |
|                 | <b>2. "Four-corner" seizure of piston(s).</b><br>a. Accelerating too fast when engine is cold. Piston expands faster than cylinder.<br><i>Replace piston(s). Ask driver to refer to warm-up procedure in Operator's Guide.</i>   |
|                 | <b>3. Piston(s) seizure on exhaust side (color on piston dome is correct).</b><br>a. Kinked fuel tank vent tube.<br><i>Relocate fuel tank vent tube.</i><br>b. Leaks at fuel line connections or damaged fuel lines.<br><i>Replace defective lines.</i><br>c. Fuel does not flow through carburetor(s) (plastic particles in needle area and/or varnish formation in carburetor(s)).<br><i>Clean carburetor(s).</i><br>d. Spark plug heat range is too warm.<br><i>Install spark plug(s) with appropriate heat range (refer to TECHNICAL DATA 10).</i><br>e. Improper ignition timing.<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i><br>f. Restriction in exhaust system.<br><i>Replace.</i><br>g. Compression ratio is too high.<br><i>Install genuine parts.</i><br>h. Carburetor calibration is too lean.<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i><br>i. Improper rotary valve timing or improper valve.<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10) and/or install Bombardier's recommended rotary valve.</i><br>j. Poor quality oil.<br><i>Use Bombardier Rotax oil.</i><br>k. Leaks at air intake silencer.<br><i>Replace air intake silencer grommets.</i> |

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

|  |  |
|--|--|
|  | <p><b>4. Melted and/or perforated piston dome; melted section at ring end gap.</b></p> <ul style="list-style-type: none"> <li>a. When piston reaches TDC, mixture is ignited by heated areas in combustion chamber. This situation is due to an incomplete combustion of a poor quality oil.<br/><i>Clean residue accumulation in combustion chamber and replace piston(s). Use Bombardier Rotax oil.</i></li> <li>b. Spark plug heat range is too high.<br/><i>Install recommended spark plug(s) (refer to TECHNICAL DATA 10).</i></li> <li>c. Ignition timing is too advanced.<br/><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i></li> <li>d. Inadequate fuel quality.<br/><i>Use appropriate fuel.</i></li> <li>e. Carburetion is too lean.<br/><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i></li> </ul> |
|  | <p><b>5. Seized piston all around the circumference (dry surface).</b></p> <ul style="list-style-type: none"> <li>a. Lack of oil, damaged oil line or defective injection pump.<br/><i>Replace defective part(s).</i></li> </ul>   |
|  | <p><b>6. Grooves on intake side of piston only.</b></p> <ul style="list-style-type: none"> <li>a. Oil film eliminated by water (snow infiltration in engine).<br/><i>Replace piston(s) and check if intake system leaks.</i></li> </ul>  |
|  | <p><b>7. Piston color is dark due to seizure on intake and exhaust sides.</b></p> <ul style="list-style-type: none"> <li>a. Broken or loose fan belt.<br/><i>Replace fan belt or adjust its tension (refer to TECHNICAL DATA 10).</i></li> <li>b. Cooling system leaks and lowers coolant level.<br/><i>Tighten clamps or replace defective parts. Add antifreeze in cooling system until appropriate level is reached.</i></li> <li>c. Accumulation of foreign particles in needle and/or main jet area.<br/><i>Clean carburetor(s).</i></li> </ul>   |
|  | <p><b>8. Cracked or broken piston(s).</b></p> <ul style="list-style-type: none"> <li>a. Cracked or broken piston(s) due to excessive piston/cylinder clearance or engine overrevving.<br/><i>Replace piston(s). Check piston/cylinder clearance (refer to TECHNICAL DATA 10). Adjust drive pulley according to specifications (refer to TECHNICAL DATA 10) and/or clean pulley sheaves if they are contaminated with greasy particles.</i></li> </ul>  |

|                 |  |
|-----------------|--|
| <b>SYMPTOM</b>  | <b>PISTON RING AND CYLINDER SURFACES ARE GROOVED.</b>  |
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <p><b>1. Check oil quality.</b></p> <ul style="list-style-type: none"> <li>a. Poor oil quality.<br/><i>Use Bombardier Rotax oil.</i></li> </ul> <p><b>2. Check injection pump and its hoses.</b></p> <ul style="list-style-type: none"> <li>a. Inadequate injection pump adjustment and/or defective hoses.<br/><i>Adjust pump according to specifications (refer to ENGINE 04) and/or replace hoses.</i></li> </ul> |

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

| SYMPTOM         | ENGINE DOES NOT OFFER MAXIMUM POWER AND/OR DOES NOT REACH MAXIMUM OPERATING RPM.   |
|-----------------|--|
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <b>1. Check spark plug condition.</b><br>a. Fouled spark plug(s).<br><i>Replace.</i>   |
|                 | <b>2. Check if there is water in fuel.</b><br>a. There is water in fuel.<br><i>Drain fuel system, then fill it with appropriate fuel.</i>  |
|                 | <b>3. Check items listed in "Engine runs out of fuel" (refer to fuel and oil system subsection 02).</b>  |
|                 | <b>4. Check carburetor adjustments and cleanliness.</b><br>a. Inadequate carburetor adjustments or dirt accumulation.<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10) or clean.</i>  |
|                 | <b>5. Check drive belt.</b><br>a. Worn belt.<br><i>Replace belt if width is 3 mm (1/8") less than nominal dimension (refer to TECHNICAL DATA 10).</i>  |
|                 | <b>6. Check track adjustment.</b><br>a. Too much tension and/or improper alignment.<br><i>Align track and adjust its tension to specifications (refer to TECHNICAL DATA 10).</i>   |
|                 | <b>7. Check drive pulley.</b><br>a. Improper calibration screw adjustments (TRA pulley) and/or worn bushing(s).<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10) and/or replace bushing(s).</i>   |
|                 | <b>8. Check driven pulley.</b><br>a. Worn bushing and/or spring tension.<br><i>Replace spring and/or adjust its tension according to specifications (refer to TECHNICAL DATA 10).</i>  |
|                 | <b>9. Check exhaust system.</b><br>a. Restriction.<br><i>Replace.</i>  |
|                 | <b>10. Check ignition timing.</b><br>a. Decrease in power due to retarded ignition.<br><i>Adjust according to specification (refer to TECHNICAL DATA 10).</i>  |
|                 | <b>11. Check engine compression.</b><br>a. Worn piston(s) and ring(s).<br><i>Replace (refer to TECHNICAL DATA 10 for specification).</i>   |
|                 | <b>12. Check engine cooling system.</b><br>a. Engine overheats. Improper fan belt tension.<br><i>Adjust fan belt (refer to TECHNICAL DATA 10).</i><br>b. Antifreeze level is low, cap fails to pressurize system or air circulates through lines.<br><i>Adjust level, replace cap or bleed cooling system.</i> |

**Section 03 TROUBLESHOOTING**  
Subsection 02 (ENGINE)

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>ENGINE DETONATION AT MAXIMUM RPM.</b>   |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check which type of fuel is used.</b><br>a. Octane number is too low and/or alcohol level is too high.<br><i>Use recommended fuel type.</i>                    |
|                        | <b>2. Check spark plug type.</b><br>a. Improper spark plug heat range.<br><i>Install recommended spark plug(s) (refer to TECHNICAL DATA 10).</i>                     |
|                        | <b>3. Check exhaust system.</b><br>a. Too much restriction.<br><i>Replace.</i>   |
|                        | <b>4. Check ignition timing.</b><br>a. Timing is too advanced.<br><i>Adjust according to specification (refer to TECHNICAL DATA 10).</i>                             |
|                        | <b>5. Check carburetion.</b><br>a. Fouled and/or improper carburetor components.<br><i>Clean or replace according to specification (refer to TECHNICAL DATA 10).</i> |
|                        | <b>6. Check compression ratio and squish area.</b><br>a. Compression ratio is too high.<br><i>Install genuine parts.</i>   |

---

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

---

| SYMPTOM         | ENGINE TURNS OVER BUT FAILS TO START.   |
|-----------------|---|
| CONDITION       | NORMAL USE.   |
| Test/Inspection | <b>1. Check switches.</b><br>a. Ignition switch, emergency cut-out switch or tether switch is in the OFF position.<br><i>Place all switches in the RUN or ON position.</i>  |
|                 | <b>2. Check fuel level.</b><br>a. Mixture not rich enough to start cold engine.<br><i>Check fuel tank level and use primer.</i>   |
|                 | <b>3. Check spark plug.</b><br>a. Defective spark plug (no spark).<br><i>Replace spark plug(s).</i>   |
|                 | <b>4. Check amount of fuel on spark plug.</b><br>a. Flooded engine (spark plug wet when removed).<br><i>Do not overprime or overchoke. Remove wet spark plug(s), turn ignition switch to OFF and crank engine several times. Install clean dry spark plug. Start engine following usual starting procedure.</i> |
|                 | <b>5. Check fuel lines.</b><br>a. No fuel to the engine (spark plug dry when removed).<br><i>Check fuel tank level; check fuel filter, replace if clogged; check condition of fuel and impulse lines and their connections.</i>   |
|                 | <b>6. Check engine compression.</b><br>a. Insufficient engine compression.<br><i>Replace defective part(s) (ex. : piston(s), ring(s), etc.).</i>  |

**Section 03 TROUBLESHOOTING**  
Subsection 02 (ENGINE)

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>IRREGULAR ENGINE IDLE.</b>  |
| <b>CONDITION</b>       | NORMAL USE AFTER ENGINE WARM UP.   |
| <b>Test/Inspection</b> | <p><b>1. Check primer.</b></p> <p>a. Fuel leaks at primer nipple which is mounted to carburetor.<br/><i>Replace.</i></p>   |
|                        | <p><b>2. Check choke.</b></p> <p>a. Choke plunger may be partially opened.<br/><i>Readjust.</i></p>  |
|                        | <p><b>3. Check carburetor adapter.</b></p> <p>a. Air enters through a crack.<br/><i>Replace.</i></p>   |
|                        | <p><b>4. Check air screw position.</b></p> <p>a. Inadequate fuel/air mixture.<br/><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i></p>            |
|                        | <p><b>5. Check ignition system trigger coil air gap.</b></p> <p>a. Air gap is too large.<br/><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i></p> |
|                        | <p><b>6. Check dimension of pilot jet.</b></p> <p>a. Inadequate fuel/air mixture.<br/><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i></p>        |
|                        | <p><b>7. Perform engine leak test.</b></p> <p>a. Leaking gaskets allow air to enter in engine.<br/><i>Replace defective parts.</i></p>                                   |



## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

| SYMPTOM         | HIGH ENGINE OPERATING TEMPERATURE.   |
|-----------------|--|
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <b>1. Check temperature gauge sensor.</b><br>a. False reading.<br><i>Replace.</i>  |
|                 | <b>2. Check fan belt.</b><br>a. Belt slides because it is too loose.<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i>  |
|                 | <b>3. Verify antifreeze level and check if there is air infiltration in the system or if there are leaks in gasket areas.</b><br>a. Low antifreeze level or air in system.<br><i>Add antifreeze until recommended level is reached, bleed system and/or tighten clamps at fitting.</i> |
|                 | <b>4. Check if antifreeze flows through system properly.</b><br>a. Foreign particles and/or broken coolant pump impeller.<br><i>Clean cooling system and/or replace coolant pump impeller.</i>   |
|                 | <b>5. Check thermostat.</b><br>a. Thermostat reacts slowly or not at all.<br><i>Replace.</i>   |
|                 | <b>6. Check antifreeze concentration.</b><br>a. Antifreeze concentration is too high.<br><i>Adjust concentration according to Bombardier's recommendations.</i>  |
|                 | <b>7. Check tank cap.</b><br>a. Cap does not hold pressure.<br><i>Replace.</i>   |
|                 | <b>8. Check carburetion.</b><br>a. Improperly adjusted or inadequate carburetor components.<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10) or replace inadequate component(s).</i>  |
|                 | <b>9. Check cylinder head gaskets.</b><br>a. Worn gaskets.<br><i>Replace.</i>  |
|                 | <b>10. Check ignition timing.</b><br>a. Ignition timing is too advanced.<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i>  |
|                 | <b>11. Check if there are leaks at air intake silencer and/or engine crankcase.</b><br>a. Leak(s).<br><i>Repair or replace.</i>  |
|                 | <b>12. Check condition and heat range of spark plug(s).</b><br>a. Melted spark plug tip or inadequate heat range.<br><i>Replace.</i>   |

**Section 03 TROUBLESHOOTING**

## Subsection 02 (ENGINE)

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>ENGINE EQUIPPED WITH RAVE VALVE DOES NOT REACH ITS FULL OPERATING RPM (500 TO 1000 RPM SLOWER).</b>                     |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check RAVE valve pistons.</b><br>a. Valve piston(s) is (are) too far out.<br><i>Screw valve piston(s) to bottom.</i> |
|                        | <b>2. Check RAVE valve stems.</b><br>a. Bent RAVE valve stem(s).<br><i>Replace.</i>  |
|                        | <b>3. Check RAVE valves.</b><br>a. Jamed valve(s).<br><i>Clean.</i>  |
|                        | <b>4. Check tension of RAVE springs.</b><br>a. Inadequate spring tension.<br><i>Replace.</i>                               |
|                        | <b>5. Check RAVE pressure holes.</b><br>a. Clogged holes.<br><i>Clean.</i>   |
|                        | <b>6. Check clamps or sleeves.</b><br>a. Damaged clamp(s) or sleeve(s).<br><i>Replace.</i>                                 |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>ENGINE EQUIPPED WITH RAVE. ENGINE HESITATES AT MID-SPEED AND REACHES MAXIMUM PERFORMANCE ONLY AFTER A WHILE.</b>                             |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check RAVE valve spring(s).</b><br>a. Spring tension is too weak or spring(s) is (are) broken.<br><i>Replace.</i>                         |
|                        | <b>2. Check RAVE valve cover red adjustment screws.</b><br>a. Adjustment screw(s) is (are) too loose.<br><i>Fully tighten.</i>                  |
|                        | <b>3. Check RAVE valve movement (RAVE movement indicator P/N 861 725 800).</b><br>a. Valve(s) is (are) stuck in open position.<br><i>Clean.</i> |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>REWIND STARTER ROPE DOES NOT REWIND.</b>                                   |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check rewind spring.</b><br>a. Broken spring.<br><i>Replace spring.</i> |

## Section 03 TROUBLESHOOTING


### Subsection 02 (ENGINE)

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>REWIND STARTER PAWL DOES NOT ENGAGE.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check stopper spring.</b><br>a. Broken stopper spring.<br><i>Replace.</i>  |
|                        | <b>2. Check pawl and pawl lock.</b><br>a. Pawl and pawl lock have stuck together because of heat.<br><i>Replace.</i>     |
|                        | <b>3. Check pawl and rope sheave.</b><br>a. Pawl and rope sheave have stuck together because of heat.<br><i>Replace.</i> |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>ENGINE PINGING.</b>  |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check fuel lines.</b><br>a. Bent fuel lines (preventing fuel from flowing through).<br><i>Relocate or replace fuel lines.</i>   |
|                        | <b>2. Check if carburetor(s) is (are) clean.</b><br>a. Dirt prevents fuel from flowing through.<br><i>Clean.</i>  |
|                        | <b>3. Check ignition timing.</b><br>a. Timing is too advanced.<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i>   |
|                        | <b>4. Check compression ratio.</b><br>a. Compression ratio is too high.<br><i>Replace inadequate part(s) to obtain manufacturer's recommended compression ratio or use a higher grade fuel.</i> |

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>ENGINE GENERATES A LOT OF VIBRATIONS.</b>   |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check engine supports.</b><br>a. Loose broken supports or interference between support(s) and chassis.<br><i>Retighten to specification (refer to TECHNICAL DATA 10) or replace.</i>                       |
|                        | <b>2. Check drive pulley (refer to: vibrations coming from drive pulley).</b>  |
|                        | <b>3. Check carburetor synchronization.</b><br>a. Throttle slide heights are adjusted differently and/or throttle slide openings are unsynchronized.<br><i>Adjust throttle slide heights and throttle cable.</i> |

**ENGINE LEAK VERIFICATION FLOW CHART**



A00C61S

# FUEL AND OIL SYSTEMS

The following chart is provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

|                 |   |
|-----------------|---|
| <b>SYMPTOM</b>  | <b>HIGH FUEL CONSUMPTION OR RICH MIXTURE.</b>   |
| CONDITION       | NORMAL USE.   |
| Test/Inspection | <p><b>1. Check fuel tank.</b></p> <p>a. Perforated fuel tank.<br/><i>Replace fuel tank.</i></p>   |
|                 | <p><b>2. Check fuel pump, reservoir and carburetor fittings.</b></p> <p>a. Leaking fittings.<br/><i>Replace defective part.</i></p>   |
|                 | <p><b>3. Check primer.</b></p> <p>a. Fuel flows through primer while engine runs.<br/><i>Replace primer.</i></p>  |
|                 | <p><b>4. Check float height in carburetor(s).</b></p> <p>a. Fuel level is too high in float bowl(s).<br/><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i></p>                  |
|                 | <p><b>5. Check needle valve.</b></p> <p>a. Foreign particles prevent needle valve(s) from closing and/or worn seating area.<br/><i>Clean or replace needle valve(s), then clean seating area.</i></p> |

|                 |  |
|-----------------|--|
| <b>SYMPTOM</b>  | <b>FUEL LEAKS IN ENGINE BASE WHEN ENGINE IS STOPPED.</b>                                     |
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <p><b>1. Check items 3, 4 and 5 of "High fuel consumption".</b></p>                          |
|                 | <p><b>2. Check fuel pump diaphragm.</b></p> <p>a. Cracked diaphragm.<br/><i>Replace.</i></p> |

## Section 03 TROUBLESHOOTING

### Subsection 03 (FUEL AND OIL SYSTEMS)

| <b>SYMPTOM</b>         | <b>ENGINE LACKS POWER OR STALLS AT HIGH RPM.</b>  |
|------------------------|---|
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check fuel tank vent hose.</b><br>a. Kinked or clogged hose.<br><i>Relocate or replace.</i> |
|                        | <b>2. Check fuel filter.</b><br>a. Clogged filter.<br><i>Replace.</i>                             |
|                        | <b>3. Check fuel lines.</b><br>a. Kinked or clogged lines.<br><i>Relocate or replace.</i>         |
|                        | <b>4. Check fuel pump flow.</b><br>a. Dried diaphragm.<br><i>Replace.</i>                         |
|                        | <b>5. Check if carburetor(s) is (are) clean.</b><br>a. Varnish.<br><i>Clean.</i>                  |

| <b>SYMPTOM</b>         | <b>HIGH INJECTION OIL CONSUMPTION.</b>   |
|------------------------|--|
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check oil injection pump adjustment.</b><br>a. Oil injection pump adjusted too rich.<br><i>Adjust.</i>   |
|                        | <b>2. Check injection pump identification.</b><br>a. Wrong pump installed.<br><i>Replace with the appropriate pump. Refer to OIL INJECTION SYSTEM 04-06.</i> |
|                        | <b>3. Check injection oil lines and their fitting.</b><br>a. Leaking lines and/or cover.<br><i>Replace defective part(s).</i>                                |
|                        | <b>4. Check injection pump cover gasket.</b><br>a. Worn gasket.<br><i>Replace.</i>   |
|                        | <b>5. Pressurize crankcase rotary valve gear reservoir.</b><br>a. Leaking gasket(s).<br><i>Replace gasket(s).</i>  |

**Section 03 TROUBLESHOOTING**  
Subsection 03 (FUEL AND OIL SYSTEMS)

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>ENGINE RUNS OUT OF FUEL (OR LEAN MIXTURE).</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check fuel filter ball located in fuel tank. Ball must move freely.</b><br>a. Corrosion due to oxidation at installation.<br><i>Replace fuel filter.</i>   |
|                        | <b>2. Check if lines are perforated or kinked and make sure they do not leak at fittings.</b><br>a. Lines are too big for their fittings or are improperly routed.<br><i>Replace or properly relocate lines.</i> |
|                        | <b>3. Check fuel pump outlet flow.</b><br>a. Dirt clogging fuel pump lines or torn membrane.<br><i>Clean or replace fuel pump.</i>   |
|                        | <b>4. Check carburetor needle valve(s).</b><br>a. Dirt (varnish, foreign particle) clogging fuel line inlets.<br><i>Clean.</i>   |
|                        | <b>5. Check main jet.</b><br>a. Dirt (varnish, foreign particle) accumulation at main jet.<br><i>Clean.</i>  |
|                        | <b>6. Check float height in carburetor bowl(s).</b><br>a. Running out of fuel at high speed because float height is too low.<br><i>Adjust float lever height according to specification.</i>                     |

# TRANSMISSION AND BRAKE SYSTEMS

The following charts are provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

## TRANSMISSION

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>THE SNOWMOBILE ACCELERATES SLOWLY, ESPECIALLY WHEN IT IS STOPPED.</b>  |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <p><b>1. Check drive belt condition.</b></p> <p>a. Belt is too narrow (drive belt engagement is higher in drive pulley).<br/><i>Replace belt if width is 3 mm (1/8 in) less than a new one (refer to TECHNICAL DATA 10).</i></p> <p><b>2. Check distance between pulleys and/or drive belt deflection.</b></p> <p>a. Distance is too small between pulleys or deflection is too high (drive belt engagement is higher in drive pulley).<br/><i>Adjust distance between pulleys and/or drive belt deflection according to specifications (refer to TECHNICAL DATA 10).</i></p> <p><b>3. Check driven pulley sliding half play.</b></p> <p>a. Jammed sliding half.<br/><i>Replace.</i></p> <p><b>4. Check spring tension of driven pulley (only on models without RER).</b></p> <p>a. Sliding half rotation is accelerated when spring tension is too weak.<br/><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i></p> <p><b>5. Refer to "Vibrations originating from driven pulley" and check items listed.</b></p> <p><b>6. Check drive pulley spring tension.</b></p> <p>a. Spring tension is too weak.<br/><i>Replace.</i></p> |

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>ENGINE MAXIMUM RPM IS TOO HIGH AND TOP SPEED IS NOT REACHED.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <p><b>1. Check items 1, 2 and 3 of "The snowmobile accelerates slowly, especially when it is stopped".</b></p> <p><b>2. Check driven pulley spring tension (only on models without RER).</b></p> <p>a. Spring tension is too stiff.<br/><i>Adjust according to specification (refer to TECHNICAL DATA 10).</i></p> <p><b>3. Check position of the calibration screws (TRA drive pulley).</b></p> <p>a. Selected numbers are too high.<br/><i>Adjust according to specification (refer to TECHNICAL DATA 10).</i></p> <p><b>4. Refer to "Vibrations originating from driven pulley" and check items listed.</b></p> |



## Section 03 TROUBLESHOOTING

### Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>LOOSENESS IS FELT IN DRIVE SYSTEM WHEN ACCELERATING/DECELERATING.</b>  |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check drive chain tension.</b><br>a. Drive chain is too loose.<br><i>Adjust.</i>  |
|                        | <b>2. Check radial play of driven pulley (aluminum frame models).</b><br>a. Worn key or keyway (splines on models with RER).<br><i>Replace.</i> |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>VIBRATIONS ORIGINATING FROM DRIVE PULLEY.</b>  |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check drive belt.</b><br>a. Belt width is uneven at many places.<br><i>Replace (refer to TECHNICAL DATA 10 for the part number).</i>  |
|                        | <b>2. Check tightening torque of drive pulley screw.</b><br>a. Moving governor cup.<br><i>Retighten screw.</i>  |
|                        | <b>3. Spring cover screws.</b><br>a. Spring cover moves and restrains sliding half movement.<br><i>Retighten screws.</i>  |
|                        | <b>4. Check spring cover (TRA TYPE) and/or outer half bushings.</b><br>a. Excessive gap between bushings and inner half shaft, thus restraining sliding half movements.<br><i>Replace bushing(s).</i> |
|                        | <b>5. Check sliding half slider shoes.</b><br>a. Worn slider shoes.<br><i>Replace.</i>  |

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>VIBRATIONS ORIGINATING FROM DRIVEN PULLEY.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check sliding half play.</b><br>a. Sliding half runout.<br><i>Replace sliding half bushing.</i>              |
|                        | <b>2. Check sliding half and fixed half straightness.</b><br>a. Sliding half/fixed half runout.<br><i>Replace.</i> |
|                        | <b>3. Check cam slider shoes.</b><br>a. One or 2 slider shoes out of 3 are broken.<br><i>Replace.</i>              |

**Section 03 TROUBLESHOOTING**  
Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>PULLEYS DO NOT DOWN SHIFT PROPERLY.</b>  |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <p><b>1. Check driven pulley spring tension.</b></p> <p>a. Spring tension is too weak.<br/><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i></p> <p><b>2. Refer to "Vibrations coming from driven pulley" and check items listed.</b></p> <p><b>3. Check drive pulley bushings (cleanliness, wear, etc.).</b></p> <p>a. Bushings stick to fixed half pulley shaft.<br/><i>Clean or replace.</i></p> <p><b>4. Check driven pulley spring tension (only on models without RER).</b></p> <p>a. Spring tension is too weak.<br/><i>Replace.</i></p> |


|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>UNEVEN BELT WEAR ON ONE SIDE ONLY.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <p><b>1. Check tightening torque of engine mount bolts.</b></p> <p>a. Loose engine mount.<br/><i>Tighten engine mount nuts/bolts equally.</i></p> <p><b>2. Check pulley alignment.</b></p> <p>a. Pulley misalignment.<br/><i>Align pulleys.</i></p> <p><b>3. Check drive belt contact area on pulleys.</b></p> <p>a. Rough or scratched pulley surfaces.<br/><i>Repair or replace pulley half.</i></p> <p><b>4. Check driven pulley sliding half play.</b></p> <p>a. Driven pulley bushing worn.<br/><i>Replace bushing.</i></p> |




A00D09Y

## Section 03 TROUBLESHOOTING


### Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

|  |   |
|--|---|
| <b>SYMPTOM</b>   | <b>BELT GLAZED EXCESSIVELY OR HAVING BAKED APPEARANCE.</b>  |
| <b>CONDITION</b>   | NORMAL USE.   |
| <b>Test/Inspection</b><br><br><br><br><small>A00D0AY</small> | <b>1. Check if drive pulley bushings are worn.</b><br>a. Insufficient pressure on belt sides.<br><i>Replace bushing.</i>                            |
|  | <b>2. Check condition of drive pulley fixed half shaft.</b><br>a. Rusted drive or driven pulley shafts.<br><i>Clean shaft with fine steel wool.</i> |
|  | <b>3. Check if pulley halves are clean.</b><br>a. Oil on pulley surfaces.<br><i>Clean pulley halves.</i>  |
|  | <b>4. Check pulley calibration.</b><br>a. Improper pulley calibration.<br><i>Calibrate according to specification.</i>                              |

|  |  |
|--|--|
| <b>SYMPTOM</b>   | <b>BELT WORN EXCESSIVELY IN TOP WIDTH.</b>   |
| <b>CONDITION</b>   | NORMAL USE.  |
| <b>Test/Inspection</b><br><br><br><br><small>A00D0BY</small> | <b>1. Check drive pulley.</b><br>a. Excessive slippage due to irregular outward actuation movement of drive pulley.<br><i>Carry out drive pulley inspection.</i> |
|  | <b>2. Check drive belt identification number.</b><br>a. Improper belt angle (wrong type of belt).<br><i>Replace belt with an appropriate drive belt.</i>         |
|  | <b>3. Check drive belt width.</b><br>a. Considerable use.<br><i>Replace belt if 3 mm (1/8 in) less than recommended width (see TECHNICAL DATA 10).</i>           |

**Section 03 TROUBLESHOOTING**  
Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>BELT WORN NARROW IN ONE SECTION.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <ol style="list-style-type: none"> <li><b>1. Check if parking brake is released.</b> <ol style="list-style-type: none"> <li>a. Parking brake is engaged.<br/><i>Release parking brake.</i></li> </ol> </li> <li><b>2. Check track tension/alignment.</b> <ol style="list-style-type: none"> <li>a. Frozen or too tight track.<br/><i>Liberate track from ice or check track tension and alignment.</i></li> </ol> </li> <li><b>3. Check drive pulley.</b> <ol style="list-style-type: none"> <li>a. Drive pulley not functioning properly.<br/><i>Repair or replace drive pulley.</i></li> </ol> </li> <li><b>4. Check idle speed.</b> <ol style="list-style-type: none"> <li>a. Engine idle speed too high.<br/><i>Adjust according to specification.</i></li> </ol> </li> <li><b>5. Check drive belt length.</b> <ol style="list-style-type: none"> <li>a. Incorrect belt length.<br/><i>Replace belt with an appropriate drive belt (refer to TECHNICAL DATA 10).</i></li> </ol> </li> <li><b>6. Check distance between pulleys.</b> <ol style="list-style-type: none"> <li>a. Incorrect pulley distance.<br/><i>Readjust according to specification.</i></li> </ol> </li> <li><b>7. Check belt deflection.</b> <ol style="list-style-type: none"> <li>a. Deflection is too small.<br/><i>Adjust according to specification.</i></li> </ol> </li> </ol> |



A00D0CY


|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>BELT SIDES WORN CONCAVE.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <ol style="list-style-type: none"> <li><b>1. Check pulley half surfaces.</b> <ol style="list-style-type: none"> <li>a. Rough or scratched pulley half surfaces.<br/><i>Repair or replace.</i></li> </ol> </li> <li><b>2. Check drive belt identification number.</b> <ol style="list-style-type: none"> <li>a. Unspecified type of belt.<br/><i>Replace belt with an appropriate drive belt (refer to TECHNICAL DATA 10).</i></li> </ol> </li> </ol> |





A00D0DY


## Section 03 TROUBLESHOOTING

### Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

|  |   |
|--|---|
| <b>SYMPTOM</b>   | <b>BELT DISINTEGRATION.</b>   |
| <b>CONDITION</b>   | NORMAL USE.   |
| <b>Test/Inspection</b><br><br><small>A00DOEY</small> | <ol style="list-style-type: none"> <li><b>1. Check drive belt identification number.</b> <ol style="list-style-type: none"> <li>Excessive belt speed.<br/><i>Using unspecified type of belt. Replace belt with proper type of belt (refer to TECHNICAL DATA 10).</i></li> </ol> </li> <li><b>2. Check if pulley halves are clean.</b> <ol style="list-style-type: none"> <li>Oil on pulley surfaces.<br/><i>Clean pulley surfaces with fine emery cloth and wipe clean using Cleaning Solvent (P/N 413 708 200) and a cloth.</i></li> </ol> </li> </ol> |


|  |   |
|--|---|
| <b>SYMPTOM</b>   | <b>BELT EDGE CORD BREAKAGE.</b>   |
| <b>CONDITION</b>   | NORMAL USE.   |
| <b>Test/Inspection</b><br><br><small>A00DOFY</small> | <ol style="list-style-type: none"> <li><b>1. Check pulley alignment.</b> <ol style="list-style-type: none"> <li>Pulley misalignment.<br/><i>Align pulley according to specifications (refer to TECHNICAL DATA 10).</i></li> </ol> </li> </ol> |

|   |  |
|---|--|
| <b>SYMPTOM</b>  | <b>FLEX CRACKS BETWEEN COGS.</b>   |
| <b>CONDITION</b>  | NORMAL USE.  |
| <b>Test/Inspection</b><br><br><small>A00D0GY</small> | <ol style="list-style-type: none"> <li><b>1. Check drive belt condition.</b> <ol style="list-style-type: none"> <li>Considerable use, belt wearing out.<br/><i>Replace.</i></li> </ol> </li> </ol> |

|  |   |
|--|---|
| <b>SYMPTOM</b>   | <b>SHEARED COGS, COMPRESSION SECTION FRACTURED OR TORN.</b>   |
| <b>CONDITION</b>   | NORMAL USE.   |
| <b>Test/Inspection</b><br><br><small>A00D0HY</small> | <ol style="list-style-type: none"> <li><b>1. Check drive belt rotational direction.</b> <ol style="list-style-type: none"> <li>Improper belt installation.<br/><i>Replace.</i></li> </ol> </li> <li><b>2. Check if drive belt rubs against components.</b> <ol style="list-style-type: none"> <li>Belt rubbing on stationary object.<br/><i>Relocate components.</i></li> </ol> </li> <li><b>3. Check drive pulley.</b> <ol style="list-style-type: none"> <li>Violent engagement of drive pulley.<br/><i>Check drive pulley engagement speed, drive pulley bushings and components.</i></li> </ol> </li> </ol> |

## Section 03 TROUBLESHOOTING

### Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

|  |   |
|--|---|
| <b>SYMPTOM</b>   | <b>BELT "FLIP-OVER" AT HIGH SPEED.</b>  |
| <b>CONDITION</b>   | NORMAL USE.   |
| <b>Test/Inspection</b>   | <ol style="list-style-type: none"> <li><b>1. Check pulley alignment.</b> <ol style="list-style-type: none"> <li>a. Pulley misalignment.<br/><i>Align pulley according to specifications (refer to TECHNICAL DATA 10).</i></li> </ol> </li> </ol>  |
| <br>A00D01Y | <ol style="list-style-type: none"> <li><b>2. Check drive belt identification number.</b> <ol style="list-style-type: none"> <li>a. Using unspecified type of belt.<br/><i>Replace belt with an appropriate drive belt.</i></li> </ol> </li> </ol> |

## BRAKE SYSTEM

### MECHANICAL BRAKE

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>BRAKE DOES NOT ADJUST AUTOMATICALLY.</b>   |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <ol style="list-style-type: none"> <li><b>1. Check ratchet wheel spring.</b> <ol style="list-style-type: none"> <li>a. Broken ratchet wheel tag.<br/><i>Replace.</i></li> </ol> </li> </ol> |
|                        | <ol style="list-style-type: none"> <li><b>2. Check mobile pad stud.</b> <ol style="list-style-type: none"> <li>a. Stud rotates in pad.<br/><i>Replace.</i></li> </ol> </li> </ol>           |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>BRAKE HANDLE DOES NOT RETURN COMPLETELY.</b>   |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <ol style="list-style-type: none"> <li><b>1. Check brake return spring.</b> <ol style="list-style-type: none"> <li>a. Broken return spring.<br/><i>Replace.</i></li> </ol> </li> </ol>  |
|                        | <ol style="list-style-type: none"> <li><b>2. Check if brake cable moves freely in its housing.</b> <ol style="list-style-type: none"> <li>a. Brake cable movement is limited due to oxidation or dirt accumulation.<br/><i>Replace.</i></li> </ol> </li> </ol>    |
|                        | <ol style="list-style-type: none"> <li><b>3. Check distance between brake lever and caliper.</b> <ol style="list-style-type: none"> <li>a. Distance is too wide.<br/><i>Adjust according to specifications (refer to TRANSMISSION 05).</i></li> </ol> </li> </ol> |

---

## Section 03 TROUBLESHOOTING

### Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

---

#### HYDRAULIC BRAKE

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>SPONGY BRAKE CONDITION.</b>   |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <i>Replace brake fluid and bleed system. If problem still occurs, replace master cylinder.</i> |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>BRAKE FLUID LEAKING.</b>   |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check for loosen hose connectors.</b><br><i>Retighten.</i>  |
|                        | <b>2. Check for damaged hose, master cylinder and caliper.</b><br><i>Replace part(s) and check for proper mounting.</i> |

#### MECHANICAL AND HYDRAULIC BRAKES

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>BRAKE SYSTEM IS NOISY.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check brake pad thickness.</b><br>a. Pads are worn up to wear warner.<br><i>Replace.</i> |

# ELECTRICAL SYSTEM

The following chart is provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

|                 |   |
|-----------------|---|
| <b>SYMPTOM</b>  | <b>STARTER DOES NOT TURN.</b>   |
| CONDITION       | NORMAL USE.   |
| Test/Inspection | <b>1. Check fuse.</b><br>a. Burnt fuse.<br><i>Check wiring condition and replace fuse.</i>  |
|                 | <b>2. Check continuity of starter switch contact points.</b><br>a. Poor contact of starter switch contact points.<br><i>Repair or replace switch.</i> |
|                 | <b>3. Check continuity between starter switch and solenoid.</b><br>a. Open circuit between starter switch and solenoid switch.<br><i>Repair.</i>      |

|                 |  |
|-----------------|--|
| <b>SYMPTOM</b>  | <b>STARTER TURNS; BUT DOES NOT CRANK THE ENGINE.</b>   |
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <b>1. Check battery capacity.</b><br>a. Shorted battery cell(s).<br><i>Replace.</i>  |
|                 | <b>2. Check battery charge.</b><br>a. Weak battery.<br><i>Recharge.</i>  |
|                 | <b>3. Check wire connection.</b><br>a. Inadequate connection (too much resistance).<br><i>Clean and reconnect.</i>                                       |
|                 | <b>4. Check solenoid switch contact disc.</b><br>a. Burnt or poor contact of solenoid switch contact disc.<br><i>Replace solenoid switch.</i>            |
|                 | <b>5. Check continuity of solenoid switch pull-in winding.</b><br>a. Open circuit of solenoid switch pull-in winding.<br><i>Replace solenoid switch.</i> |
|                 | <b>6. Check continuity of solenoid switch hold-in winding.</b><br>a. Open circuit of solenoid switch hold-in winding.<br><i>Replace solenoid switch.</i> |



---

## Section 03 TROUBLESHOOTING

### Subsection 05 (ELECTRICAL SYSTEM)

---

|  |   |
|--|---|
|  | <p><b>7. Check brushes.</b></p> <p>a. Poor contact of brushes.<br/><i>Replace brushes.</i></p>  |
|  | <p><b>8. Check commutator.</b></p> <p>a. Burnt commutator.<br/><i>Turn commutator on a lathe. Respect outer diameter wear limit. Refer to ELECTRIC STARTER 06-06.</i></p> |
|  | <p><b>9. Check height of commutator mica.</b></p> <p>a. Commutator mica too high.<br/><i>Undercut mica.</i></p>   |
|  | <p><b>10. Check field coil resistance.</b></p> <p>a. Shorted field coil.<br/><i>Repair or replace yoke.</i></p>   |
|  | <p><b>11. Check armature resistance.</b></p> <p>a. Shorted armature.<br/><i>Repair or replace armature.</i></p>   |
|  | <p><b>12. Check tension of brush springs.</b></p> <p>a. Weak brush spring tension.<br/><i>Replace springs.</i></p>  |
|  | <p><b>13. Check yoke assembly magnets.</b></p> <p>a. Weak magnets.<br/><i>Replace yoke assembly.</i></p>  |
|  | <p><b>14. Check if bushings are worn.</b></p> <p>a. Worn bushings.<br/><i>Replace bushings.</i></p>   |

**Section 03 TROUBLESHOOTING**  
Subsection 05 (ELECTRICAL SYSTEM)

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>STARTER TURNS, BUT OVERRUNNING CLUTCH PINION DOES NOT MESH WITH RING GEAR.</b>                                     |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check clutch pinion gear.</b><br>a. Worn clutch pinion gear.<br><i>Replace clutch.</i>                          |
|                        | <b>2. Check clutch.</b><br>a. Defective clutch.<br><i>Replace clutch.</i>   |
|                        | <b>3. Check movement of clutch on splines.</b><br>a. Poor movement of clutch on splines.<br><i>Clean and correct.</i> |
|                        | <b>4. Check clutch bushing.</b><br>a. Worn clutch bushing.<br><i>Replace clutch.</i>                                  |
|                        | <b>5. Check starter bushings.</b><br>a. Worn starter bushing(s).<br><i>Replace bushing(s).</i>                        |
|                        | <b>6. Check ring gear.</b><br>a. Worn ring gear.<br><i>Replace ring gear.</i>   |

---

## Section 03 TROUBLESHOOTING

### Subsection 05 (ELECTRICAL SYSTEM)

---

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>ELECTRIC STARTER KEEPS TURNING WHEN ENGINE IS STARTED.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check clutch.</b><br>a. Jammed clutch pinion gear.<br><i>Replace or clean.</i>   |
|                        | <b>2. Check movement of clutch on splines.</b><br>a. Clutch is stuck on splines.<br><i>Clean.</i>  |
|                        | <b>3. Check ignition switch.</b><br>a. Ignition switch does not return to its ON position or is short-circuited.<br><i>Replace switch.</i> |
|                        | <b>4. Check solenoid.</b><br>a. Shorted solenoid switch winding(s).<br><i>Replace solenoid switch.</i>                                     |
|                        | <b>5. Check solenoid switch contacts.</b><br>a. Melted solenoid switch contacts.<br><i>Replace solenoid switch.</i>                        |
|                        | <b>6. Check starter switch.</b><br>a. Starter switch returns poorly.<br><i>Replace ignition switch.</i>                                    |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>NOISE OCCURENCE WHEN STARTING ENGINE.</b>  |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check if ring gear is well mounted to drive pulley inner half.</b><br>a. Loose and/or broken bolts.<br><i>Retighten bolts using thread-locker or replace ring gear and drive pulley inner half.</i> |

**Section 03 TROUBLESHOOTING**  
Subsection 05 (ELECTRICAL SYSTEM)

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>ELECTRIC STARTER SOMETIMES DOES NOT WORK WHEN TURNING IGNITION SWITCH.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <p><b>1. Check battery cables and starter wires.</b></p> <p>a. Corroded and/or loose connection(s).<br/><i>Clean and/or retighten.</i></p>   |
| <b>Test/Inspection</b> | <p><b>2. Check fuse.</b></p> <p>a. Oxidized fuse.<br/><i>Clean.</i></p>  |
| <b>Test/Inspection</b> | <p><b>3. Check wiring harness connections.</b></p> <p>a. Oxidized connections.<br/><i>Clean or replace defective terminals.</i></p>          |
| <b>Test/Inspection</b> | <p><b>4. Check ignition switch.</b></p> <p>a. Defective contacts in ignition switch.<br/><i>Replace.</i></p>                                 |
| <b>Test/Inspection</b> | <p><b>5. Check solenoid of electric starter.</b></p> <p>a. Shorted solenoid wiring harness or eroded contact washer.<br/><i>Replace.</i></p> |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>HEADLAMP NOT LIGHTING.</b>   |
| <b>CONDITION</b>       | WHITE BULB.   |
| <b>Test/Inspection</b> | <p><b>1. Check bulb.</b></p> <p>a. Gas leak.<br/><i>Replace bulb.</i></p>   |
| <b>CONDITION</b>       | BROKEN ELEMENT.   |
| <b>Test/Inspection</b> | <p><b>1. Check for loose headlamp housing and bulb socket.</b></p> <p>a. Vibration problem.<br/><i>Tighten headlamp mounting screws. Lock bulb in socket. Replace bulb.</i></p>   |
| <b>CONDITION</b>       | MELTED FILAMENT (ENDS OF ELEMENT HOLDER) AND BLACK BULB.  |
| <b>Test/Inspection</b> | <p><b>1. Check voltage at headlamp at different speeds. It must not be above 15 Vac.</b></p> <p>NOTE: If quartz halogen bulb is involved, ensure that proper voltage regulator is installed.</p> <p>a. Excessive voltage in lighting circuit.<br/><i>Replace voltage regulator and ensure proper grounding. Retest.</i></p> |

## Section 03 TROUBLESHOOTING

### Subsection 05 (ELECTRICAL SYSTEM)

| SYMPTOM         | HEADLAMP DIMING.   |
|-----------------|--|
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <b>1. Check voltage at headlamp at different speeds. It must not be below 11 Vac.</b><br>a. Insufficient voltage in lighting circuit.<br><i>Replace voltage regulator and retest.</i>  |
|                 | <b>2. Visually inspect wiring harness for damaged and/or melted wires and/or bad wire terminal crimping and/or connections.</b><br>a. Heating, rotating or sharp part in contact with harness. Improper harness routing.<br><i>Repair/replace damaged wires and/or terminals. Reroute harness where necessary.</i> |
|                 | <b>3. On manual start models: Verify regulator ground.</b><br>a. Rusted or loose retaining screws.<br><i>Clean, apply lithium grease (LMZ1) and firmly tighten screws.</i>   |
|                 | <b>4. Verify if there is an interconnection between AC and DC current.</b><br>a. Faulty installation of optional equipment.<br><i>Find optional equipment connected directly to DC ground (BK wire or chassis) or to any DC hot wire (RD, RD/BL). Disconnect and reconnect to AC current (YL and YL/BK wires).</i> |
|                 | <b>5. Verify if optional electric accessories are overloading the magneto/generator.</b><br>a. Excessive electrical load to magneto/generator.<br><i>Reduce the electrical load by removing excess accessories. Reconnect as recommended by manufacturer.</i>  |
|                 | <b>6. Hot Grips brand: Verify if they were connected in parallel by mistake.</b><br>a. Excessive electrical load to magneto/generator.<br><i>Reconnect as recommended by manufacturer.</i>   |
|                 | <b>7. Bombardier heating grips: Verify if the return wires of the elements were grounded to the chassis by mistake.</b><br>a. Faulty installation of optional equipment.<br><i>Reconnect as recommended by manufacturer.</i>   |
|                 | <b>8. Verify if heating grips installation overloads the magneto/generator capacity.</b><br>a. Excessive electrical load to magneto/generator.<br><i>Reduce the electrical load by removing accessories.</i>   |

**Section 03 TROUBLESHOOTING**  
Subsection 05 (ELECTRICAL SYSTEM)

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>FALSE FUEL AND/OR TEMPERATURE GAUGE READINGS.</b>  |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <p><b>1. Verify if gauge was connected on DC current by mistake (in case of optional installation).</b></p> <p>a. Faulty installation of optional equipment.<br/><i>Find optional wires connected directly to DC ground (BK wire to chassis) or to any DC hot wire (RD, RD/BL). Disconnect and reconnect to AC current (YL and YL/BK wires).</i></p> <p><b>2. Verify sender unit for free movement and/or correct arm position.</b></p> <p>a. Defective or damaged part.<br/><i>Correct or replace sender unit.</i></p> <p><b>3. Verify sender unit/gauge wiring harness condition.</b></p> <p>a. Heating, rotating or sharp part in contact with harness. Improper harness routing.<br/><i>Replace or repair damaged wires. Reroute where necessary.</i></p> |

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>ENGINES DOES NOT START — NO SPARK AT SPARK PLUG.</b>  |
| <b>CONDITION</b>       | AT ENGINE CRANKING.  |
| <b>Test/Inspection</b> | <p><b>1. Verify spark plug condition.</b></p> <p>a. Defective, improperly set, worn-out, fouled.<br/><i>Identify source of problem and correct. Replace spark plug.</i></p> <p><b>2. Verify spark plug cap resistance with an ohmmeter.</b></p> <p>a. Defective part.<br/><i>Replace cap.</i></p> <p><b>3. Verify if problem originated from electrical system wiring harness and/or accessories and/or ignition cut-out switches by unplugging the BLACK/YELLOW wire between the magneto/generator and the vehicle wiring harness. Check condition of connectors.</b></p> <p>a. Heating, rotating or sharp part in contact with harness. Improper harness routing. Defective switch(es). Corroded connector terminals.<br/><i>Replace or repair damaged wires. Reroute where necessary. Replace defective switch(es). Clean connectors and apply silicone dielectric grease.</i></p> <p><b>4. Verify trigger coil resistance with an ohmmeter and connector condition.</b></p> <p>a. Defective coil. Corroded connector terminals.<br/><i>Replace defective coil. Clean terminals and apply silicone dielectric grease.</i></p> <p><b>5. Verify condition of ignition coil.</b></p> <p>a. Mechanically damaged part. Vibration problem. Electrically damaged part.<br/><i>Tighten mounting screws. Replace ignition coil.</i></p> <p><b>6. Verify condition of ignition generator coils.</b></p> <p>a. Mechanically damaged part. Vibration problem. Electrically damaged part.<br/><i>Tighten mounting screws. Replace coils.</i></p> <p><b>7. Verify CDI (Capacitor Discharge Ignition) module.</b></p> <p>a. Mechanically damaged part. Vibration problem. Electrically damaged part.<br/><i>Tighten mounting screws. Replace CDI module, retest and verify ignition timing.</i></p> |

## Section 03 TROUBLESHOOTING

### Subsection 05 (ELECTRICAL SYSTEM)

|                 |  |
|-----------------|--|
| <b>SYMPTOM</b>  | <b>ENGINE STALLS.</b>                    |
| CONDITION       | AT LOW SPEED.                            |
| Test/Inspection | <b>1. Verify items 4, 5 and 6 above.</b> |

|                 |   |
|-----------------|---|
| <b>SYMPTOM</b>  | <b>IRREGULAR ENGINE SPEED.</b>  |
| CONDITION       | AT HIGH SPEED.  |
| Test/Inspection | <b>1. Verify items 4, 5 and 6 above.</b>  |
| CONDITION       | AT LOW SPEED.   |
| Test/Inspection | <b>1. Verify items 4 and 5 above and trigger coil/flywheel protrusion air-gap.</b><br>a. Air-gap too large.<br><i>Readjust air-gap.</i> |

|                 |  |
|-----------------|--|
| <b>SYMPTOM</b>  | <b>ENGINE IS MISFIRING — ERRATIC SPARK AT SPARK PLUG.</b>  |
| CONDITION       | RIDING ON WET SNOW.  |
| Test/Inspection | <b>1. Verify if spark plug wires and/or spark plug cap seals are sealing-out moisture.</b><br>a. Defective wires and/or seals.<br><i>Replace defective part.</i>   |
|                 | <b>2. Verify if ignition system wiring harness connectors are in good condition and/or are sealing-out moisture.</b><br>a. Loose connectors, corroded terminals or defective parts.<br><i>Clean terminals and apply silicone dielectric grease. Replace defective parts.</i>   |
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <b>1. Verify misfiring by observing flash of stroboscopic timing light; unplug connectors between magneto/generator and vehicle wiring harness to isolate problem. Check condition of connectors.</b><br>a. Defective spark plug and/or cables/caps. Defective electrical system wiring harness and/or accessories and/ignition cut-out switches. Condition of connector terminals.<br><i>Replace defective parts and/or repair damaged wires. Replace defective switch(es). Clean terminals and apply silicone dielectric grease.</i> |
| CONDITION       | RIDING IN DEEP AND THICK SNOW.   |
| Test/Inspection | <b>1. Perform all verifications outlined under “Engine does not start — no spark at spark plug”.</b>   |
|                 | <b>2. Verify spark plug(s). Proceed with spark plug analysis in order to identify source of problem.</b><br>a. Defective and/or worn spark plug(s) and/or cable(s) and/or cap(s).<br><i>Replace defective part(s). Proceed with ignition system testing procedures. Perform engine analysis.</i>   |

**Section 03 TROUBLESHOOTING**  
**Subsection 05 (ELECTRICAL SYSTEM)**

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>FOULED (BLACK) SPARK PLUG TIP.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <p><b>1. Check carburetor(s).</b><br/> a. Carburetion is too rich.<br/> <i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i></p> <p><b>2. Check injection oil consumption.</b><br/> a. Injection pump flow is too high.<br/> <i>Adjust according to specification or replace.</i></p> <p><b>3. Check oil quality.</b><br/> a. Poor oil quality that creates deposits.<br/> <i>Use Bombardier oil.</i></p> <p><b>4. Check engine compression.</b><br/> a. Leaking piston ring(s).<br/> <i>Replace.</i></p> |

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>SPARK PLUG TIP(S) IS (ARE) LIGHT GREY.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <p><b>1. Refer to “Engine slows down or stops at high RPM” and check items listed.</b></p> <p><b>2. Check spark plug heat range.</b><br/> a. Spark plug heat range is too high.<br/> <i>Replace by Bombardier’s recommended spark plug (refer to TECHNICAL DATA 10).</i></p> <p><b>3. Check if air intake silencer leaks.</b><br/> a. Air surplus coming from opening(s) located between halves.<br/> <i>Seal.</i></p> <p><b>4. Check carburetor adapter collars.</b><br/> a. Loose collar(s).<br/> <i>Tighten.</i></p> <p><b>5. Check carburetor adapter(s).</b><br/> a. Cracked or deformed adapter(s).<br/> <i>Replace.</i></p> |

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>BRAKE LIGHT REMAINS ON.</b>   |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <p><b>1. Check if bulb is properly installed.</b><br/> a. Bulb is not installed correctly (contact elements are reversed).<br/> <i>Install bulb correctly.</i></p> <p><b>2. Check brake switch.</b><br/> a. Switch contact remains closed.<br/> <i>Adjust brake cable or brake switch.</i></p> |



---

## Section 03 TROUBLESHOOTING

### Subsection 05 (ELECTRICAL SYSTEM)

---

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>REAR LIGHT BULB FLASHES.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check bulb tightness in housing.</b><br>a. Looseness at bulb contact elements.<br><i>Install bulb correctly.</i>                             |
|                        | <b>2. Check if rear light is properly connected.</b><br>a. Connector housing is partially connected.<br><i>Install connector housing properly.</i> |
|                        | <b>3. Check continuity of wires.</b><br>a. Corroded terminals and/or broken wires.<br><i>Replace terminal(s) or crimp defective wires.</i>         |

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>TACHOMETER DOES NOT WORK.</b>   |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check fuse.</b><br>a. Burnt fuse.<br><i>Replace.</i>   |
|                        | <b>2. Check continuity of wires.</b><br>a. Corroded terminals and/or broken wires.<br><i>Replace terminal(s) or crimp defective wires.</i> |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>HIGH BEAM PILOT LAMP LIGHTS UP WHEN LOW BEAM IS SELECTED.</b>  |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check proper connections.</b><br>a. Yellow wire connected to pilot lamp. Mixed-up connections with heating element pilot lamps.<br><i>Reconnect a YELLOW/BLACK wire to pilot lamp. YELLOW wires are connected to heating element pilot lamps.</i> |

# SUSPENSION AND TRACK

The following chart is provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

|                        |  |
|------------------------|--|
| <b>SYMPTOM</b>         | <b>REAR SUSPENSION BOTTOMS OUT.</b>  |
| <b>CONDITION</b>       | NORMAL USE.  |
| <b>Test/Inspection</b> | <b>1. Check rear spring preload or rear arm spring preload.</b><br>a. Spring tension is too low.<br><i>Increase rear arm spring preload.</i> |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>SLIDER SHOES WEAR OUT PREMATURELY.</b>   |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check track tension.</b><br>a. Pressure is too great on slider shoes.<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i><br><i>Replace defective parts.</i> |

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>TRACK CLEATS BECOME BLUE.</b>  |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check track tension.</b><br>a. Pressure is too great on cleats.<br><i>Adjust according to specifications (refer to TECHNICAL DATA 10).</i>                                  |
|                        | <b>2. Check slider shoes and/or suspension retaining screws.</b><br>a. Worn slider shoes or lost retaining screws.<br><i>Replace defective parts and/or tighten loose screws.</i> |

## Section 03 TROUBLESHOOTING

### Subsection 06 (SUSPENSION AND TRACK)

| SYMPTOM         | NOISE OR VIBRATIONS ORIGINATING FROM THE TRACK.   |
|-----------------|---|
| CONDITION       | NORMAL USE.   |
| Test/Inspection | <b>1. Check slide suspension retaining bolts.</b><br>a. Missing bolt(s) allowing movement of certain components which in turn interfere with track rotation.<br><i>Replace missing bolt(s).</i> |
|                 | <b>2. Check condition of idler wheel(s).</b><br>a. Idle wheel rubber is damaged.<br><i>Replace.</i>   |
|                 | <b>3. Check guide cleats.</b><br>a. Top portion of guide cleat(s) is bent.<br><i>Replace.</i>   |
|                 | <b>4. Check sprockets.</b><br>a. One or various teeth of drive shaft sprockets are broken.<br><i>Replace sprocket(s).</i>   |
|                 | <b>5. Check track rods and/or internal traction teeth.</b><br>a. One or various track rods and/or teeth are broken.<br><i>Replace track.</i>  |

| SYMPTOM         | DERAILING TRACK.  |
|-----------------|---|
| CONDITION       | NORMAL USE.   |
| Test/Inspection | <b>1. Check track tension.</b><br>a. Track is too loose.<br><i>Adjust.</i>                                  |
|                 | <b>2. Check if track and slider shoes are properly aligned.</b><br>a. Improper alignment.<br><i>Adjust.</i> |

| SYMPTOM         | REAR SUSPENSION IS LOW OR TOO STIFF.   |
|-----------------|--|
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <b>1. Check track tension.</b><br>a. Track is too tight.<br><i>Adjust.</i>   |
|                 | <b>2. Check if axles are properly lubricated.</b><br>a. Improper lubrication and/or contaminated grease (sticky oil sludge).<br><i>Clean and/or lubricate.</i> |
|                 | <b>3. Check rear spring preload.</b><br>a. Insufficient preload.<br><i>Increase preload using shock adjustment cams.</i>                                       |

**Section 03 TROUBLESHOOTING**  
Subsection 06 (SUSPENSION AND TRACK)

|                 |  |
|-----------------|--|
| <b>SYMPTOM</b>  | <b>WHEN HANDLEBAR IS TURNED, SNOWMOBILE UNDERSTEERS.</b>   |
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <b>1. Check ski runner condition.</b><br>a. Worn ski runners.<br><i>Replace.</i>   |
|                 | <b>2. Check tension of front spring adjustment cams.</b><br>a. Insufficient ski pressure on the ground.<br><i>Increase spring preload.</i> |
|                 | <b>3. Check if front arm stopper strap is too long.</b><br>a. Insufficient ski pressure on the ground.<br><i>Shorten stopper strap.</i>    |
|                 | <b>4. Check front arm spring tension.</b><br>a. Insufficient ski pressure on the ground.<br><i>Reduce spring preload.</i>                  |

|                 |  |
|-----------------|--|
| <b>SYMPTOM</b>  | <b>HANDLE BAR IS DIFFICULT TO TURN.</b>  |
| CONDITION       | NORMAL USE.  |
| Test/Inspection | <b>1. Check position of front spring adjustment cams.</b><br>a. More pressure on the ground when cam increases spring preload.<br><i>Reduce front spring preload.</i>        |
|                 | <b>2. Check position of stopper strap.</b><br>a. More weight when stopper strap is short.<br><i>Lengthen front arm stopper strap.</i>  |
|                 | <b>3. Check position of front arm shock adjustment cam(s).</b><br>a. When spring tension is weak, more weight is transferred to the skis.<br><i>Increase spring preload.</i> |
|                 | <b>4. Check condition of ball joints.</b><br>a. Corrosion restrains movement.<br><i>Lubricate or replace.</i>  |
|                 | <b>5. Check straightness of suspension components.</b><br>a. Bent component(s).<br><i>Replace as required.</i>   |

---

## Section 03 TROUBLESHOOTING

### Subsection 06 (SUSPENSION AND TRACK)

---

|                        |   |
|------------------------|---|
| <b>SYMPTOM</b>         | <b>THE SNOWMOBILE IS UNSTABLE (IT MOVES FROM LEFT TO RIGHT AND VICE VERSA).</b>   |
| <b>CONDITION</b>       | NORMAL USE.   |
| <b>Test/Inspection</b> | <b>1. Check ski runner condition.</b><br>a. Worn or bent ski runners.<br><i>Replace ski runners.</i>  |
|                        | <b>2. Check ski alignment.</b><br>a. Improper ski alignment.<br><i>Align skis in order to obtain proper toe-out (opening) (to adjust, refer to STEERING SYSTEM 08).</i> |
|                        | <b>3. Check if bushings are too loose in steering system.</b><br>a. Bushings are too loose.<br><i>Replace.</i>  |