

# TABLE OF CONTENTS

<b>DRIVE BELT</b> .....	<b>05-02-1</b>
<b>2000 APPLICATION CHART</b> .....	<b>05-02-1</b>
ROTATION DIRECTION .....	05-02-1
DRIVE BELT DEFLECTION MEASUREMENT .....	05-02-2
DEFLECTION ADJUSTMENT .....	05-02-3
<b>DRIVE PULLEY</b> .....	<b>05-03-1</b>
<b>TRA</b> .....	<b>05-03-1</b>
GENERAL .....	05-03-2
REMOVAL .....	05-03-2
DISASSEMBLY .....	05-03-2
CLEANING .....	05-03-4
INSPECTION .....	05-03-4
ASSEMBLY .....	05-03-5
INSTALLATION .....	05-03-7
DRIVE PULLEY ADJUSTMENT .....	05-03-8
<b>DRIVEN PULLEY</b> .....	<b>05-04-1</b>
REMOVAL .....	05-04-2
DISASSEMBLY .....	05-04-2
CLEANING .....	05-04-2
INSPECTION .....	05-04-2
ASSEMBLY .....	05-04-3
INSTALLATION .....	05-04-3
ADJUSTMENT .....	05-04-3
REMOVAL .....	05-04-6
DISASSEMBLY .....	05-04-6
CLEANING .....	05-04-6
INSPECTION .....	05-04-6
ASSEMBLY .....	05-04-6
INSTALLATION .....	05-04-7
ADJUSTMENT .....	05-04-7
<b>PULLEY DISTANCE AND ALIGNMENT</b> .....	<b>05-05-1</b>
GENERAL .....	05-05-1
GENERAL PROCEDURE .....	05-05-1
PULLEY ALIGNMENT AND DISTANCE SPECIFICATIONS CHART .....	05-05-2

---

## Section 05 TRANSMISSION

### Subsection 01 (TABLE OF CONTENTS)

---

---

<b>BRAKE</b> .....	<b>05-06-1</b>
<b>HYDRAULIC DISC BRAKE</b> .....	<b>05-06-1</b>
REMOVAL .....	05-06-2
DISASSEMBLY .....	05-06-2
CLEANING .....	05-06-2
INSPECTION .....	05-06-2
INSTALLATION .....	05-06-2
ADJUSTMENT.....	05-06-3
BLEEDING.....	05-06-3
<b>CHAINCASE</b> .....	<b>05-07-1</b>
REMOVAL .....	05-07-2
INSPECTION .....	05-07-2
GEAR RATIO MODIFICATION.....	05-07-2
INSTALLATION .....	05-07-2
DRIVE CHAIN ADJUSTMENT.....	05-07-3
ADJUSTMENT.....	05-07-3
<b>DRIVE CHAIN</b> .....	<b>05-08-1</b>
SILENT CHAIN.....	05-08-1

---


# DRIVE BELT

## 2000 APPLICATION CHART


MODEL	PART NUMBER	WIDTH (NEW) ± 0.25 mm (.010 in)	MINIMUM WIDTH (WEAR LIMIT) mm (in)
CK3 Series	417 300 066	35.10 (1.382)	33.00 (1.299)

### ROTATION DIRECTION

The maximum drive belt life span is obtained when the drive belt is installed as shown. This will ensure that correct direction of rotation is respected.



**CORRECT**



**INCORRECT**

**NOTE:** For used drive belt, mark and reinstall in the same position.

## Section 05 TRANSMISSION

### Subsection 02 (DRIVE BELT)

## DRIVE BELT DEFLECTION MEASUREMENT

**NOTE:** The drive belt deflection measurement must be performed each time a new drive belt is installed.

**NOTE:** To obtain an accurate drive belt deflection measurement, it is suggested to allow a break-in period of 50 km (30 mi).

Before checking the belt deflection, ensure vehicle has the proper belt (refer to the application chart).

Adjust pulley distance and alignment. Refer to PULLEY DISTANCE AND ALIGNMENT 05-05.

To obtain maximum vehicle performance, the belt tension must be adjusted according to specifications shown in the accompanying chart.


MODEL	DEFLECTION mm (in)	FORCE kg (lb)	HEIGHT† OVER DRIVEN PULLEY
All models	38 ± 5 (1.496 ± .197)	11.5 (25)	0 - 1.5 mm (0 - 1/16 in)

† FOR REFERENCE ONLY

### To Check Tension


Position a reference rule on drive belt.

### Wooden Stick and Spring Scale Method




1. Mark specified deflection

Using spring scale and stick, apply specified force on drive belt halfway between pulleys as shown.




1. Force
2. Read deflection here
3. Reference rule

Or use the belt tension tester (P/N 414 348 200).



1. Lower O-ring
2. Upper O-ring
3. Force (read down)
4. Deflection (read up)

1. Slide lower O-ring of deflection scale to specified measure.
2. Slide upper O-ring to 0 (zero) on the force scale.
3. Apply pressure until lower O-ring is flush with edge of rule and read force on the upper scale at top edge of O-ring.



1. Upper O-ring — force
2. Force
3. Lower O-ring — deflection
4. Reference rule
5. Deflection

## DEFLECTION ADJUSTMENT

Adjust pulley distance according to specification, refer to PULLEY DISTANCE AND ALIGNMENT 05-05.


### **Models Equipped with Formula Type Driven Pulley**

Adjust drive belt deflection using Allen screws, as shown.

To increase deflection: turn Allen screws clockwise.

To decrease deflection: turn Allen screws counter-clockwise.


**NOTE:** Turn Allen screws 1/4 turn at a time, then rotate driven pulley to allow drive belt to settle in pulley. Check deflection, repeat as required.



### **TYPICAL**

1. Allen screw with jam nut

Allen screws must be restrained while tightening jam nut to prevent throwing adjustment out. Use drive belt tension adjuster (P/N 529 008 700).



### **TYPICAL**

### **Models Equipped with HPV27 Type Driven Pulley**


Loosen screws and turn adjustment ring accordingly.

# DRIVE PULLEY

## TRA

All Models

NOTE: This is a lubrication free drive pulley.



## Section 05 TRANSMISSION

### Subsection 03 (DRIVE PULLEY)

## GENERAL

Some drive pulley components (return spring, ramp) can be changed to improve vehicle performance in high altitude regions. The *High Altitude and Sea Level Technical Data Booklet* (P/N 484 200 019 and 484 054 500 for binder) gives information about calibration according to altitude.

**CAUTION:** Such modifications should only be performed by experienced mechanics since they can greatly affect vehicle performance. Verify spring specifications before installation. Do not only refer to the spring color code.

**NOTE:** TRA drive pulley stands for Total Range Adjustable drive pulley.


### **⚠ WARNING**

Any drive pulley repairs must be performed by an authorized Bombardier snowmobile dealer, or other such qualified person. Sub-component installation and assembly tolerances require strict adherence to procedures detailed.

## REMOVAL

### 30,31, Conical Spring Washer and Screw

Use holder (P/N 529 006 400).



#### TYPICAL

1. Retaining screw
2. Insert in any slot

### **⚠ WARNING**

Never use any type of impact wrench at drive pulley removal and installation.

Remove retaining screw.

To remove drive pulley ass'y and/or fixed half from engine, use puller (P/N 529 022 400).

**CAUTION:** These pulleys have metric threads. Do not use imperial threads puller. Always tighten puller by hand to ensure that the drive pulley has the same type of threads (metric vs imperial) prior to fully tightening.

To Remove Drive Pulley Ass'y:

Retain drive pulley with clutch holder.

Install puller in pulley shaft then tighten.

## DISASSEMBLY


### 1,2, Screw and Ring Gear

**CAUTION:** Retaining screws must be heated before disassembly. Do not exceed 150°C (300°F).

### 5,6, Fixed and Sliding Half

**CAUTION:** Do not tap on governor cup.

Screw puller into fixed half shaft about 13 mm (1/2 in). Raise drive pulley and hold it by the sliding half while knocking on puller head to disengage fixed half.




1. Puller
2. Holding sliding half

**NOTE:** No components marking is required before disassembling this drive pulley since it has factory mark and arrows as indexing reference.

### 25,29, Slider Shoe and Governor Cup


Carefully lift governor cup until slider shoes come at their highest position into guides.

Hold a slider shoe set then carefully lift its housing and remove slider shoes. Proceed the same way for other housings lifting one at a time.



1. Hold slider shoes
2. Lift one housing at a time

**NOTE:** To ease disassembly, forks (P/N 529 005 500) should be used to hold slider shoes prior to removing governor cup.




### 19, Spring Cover Ass'y

It is pushed by clutch spring pressure.

#### **⚠ WARNING**


Clutch spring is very strong. Never attempt to remove spring cover without the recommended tools.

Use spring compressor (P/N 529 035 524).  
Install support guide.



1. Support guide

Install sliding half then a second support guide. These support guides will prevent bushing damages.



1. Support guide

Remove 3 Allen screws retaining spring cover then unscrew compressor.



---

## Section 05 TRANSMISSION

### Subsection 03 (DRIVE PULLEY)

---

## CLEANING

### 5,6, Fixed and Sliding Half

Clean pulley faces and shaft with fine steel wool and dry cloth.

### 5, Fixed Half and Crankshaft End

Parts must be at room temperature before cleaning.

Using a paper towel with cleaning solvent, clean crankshaft tapered end and the taper inside the fixed half of the drive pulley, crankshaft threads and retaining screw threads.

#### WARNING

This procedure must be performed in a well-ventilated area.

**CAUTION:** Avoid contact between cleaner and crankshaft seal because damage may occur.

Remove all hardened oil deposits that have baked on crankshaft and pulley tapered surfaces with coarse or medium steel wool and/or sand paper no. 600.

**CAUTION:** Do not use any other type of abrasive.

Reclean mounting surfaces with paper towel and cleaning solvent.

Wipe off the mounting surfaces with a clean, dry paper towel.

**CAUTION:** Mounting surfaces must be free of any oil, cleaner or towel residue.

### 7,20, Bushing

Only use petrol base cleaner when cleaning bushings.

**CAUTION:** Do not use acetone to clean bushing.

## INSPECTION

Drive pulley should be inspected annually.

### 16,17, Thrust Washer and Roller

Check roller for roundness of external diameter. Check thrust washer for thickness wear. Replace as required.

**CAUTION:** Ensure rollers are in good condition. Replace as required.

### 9,12, Fitting Bolt Ass'y and Flanged Bushing

Check for wear, replace as required. When installing old style flanged bushing (made of black plastic), use a size "O" (letter) drill bit to ream inside diameter.

### 24,25, O-Ring and Slider Shoe

Check if O-rings are cracked, cut or crushed. Replace as required.

Check slider shoes for wear. Replace if groove is not apparent on top.

### 5,29, Fixed Half and Governor Cup

Inspect splines and free play between both parts. Maximum free play is 0.5 mm (.020 in) measured at calibration screw radius. Replace if required.

### 7,20, Sliding Half and Spring Cover Bushing

Visually inspect coating. Replace if worn.

#### Sliding Half Bushing Replacement


This bushing is not replacable. If worn out, replace sliding half ass'y.

#### Spring Cover Bushing Replacement

Under normal use there is no need to replace this bushing.

Mount compressor (P/N 529 035 524) in a vise.

Use tools (P/N 529 031 300 and 529 031 200) to remove old bushing.



**CAUTION:** Bushing must be bonded with retaining compound.

Apply retaining compound Loctite 609 outside of bushing then press it down to counterbore from outside end.

**CAUTION:** Insert bushing from sliding half side (inner side) of spring cover.

## ASSEMBLY


**NOTE:** This drive pulley is lubrication free. Do not lubricate any component.

### 1,2,3, Screw, Ring Gear and Loctite 271

Apply Loctite 271 (P/N 413 702 900) on threads and then torque to 27 N•m (20 lbf•ft).

### 26,27,28, Calibration Screw, Washer and Locking Nut

When installing calibration screw, make sure to install washer as shown.



1. Washer


Torque locking nut to 10 N•m (89 lbf•in).

### 15, Pin

Always use the same type of pin as originally installed when servicing. Different types have different weights for calibration purpose. Refer to TECHNICAL DATA 10-03.


### 21,22,23, Ramp, Dowel Tube and Screw

Insert dowel tube from chamfered side. Make sure ramp is centered on dowel tube.




1. Chamfered side

Position dowel tube split at the illustrated angle.



## Section 05 TRANSMISSION

### Subsection 03 (DRIVE PULLEY)



1. Equal distance


Torque screws to 10 N•m (89 lbf•in).

### 9,11,13,14, Screw, Lever Ass'y, Nut and Cotter Pin

Always install lever assemblies so that cotter pins are on the shown side. Besides install cotter pin head on top when lever is sat at bottom of sliding half. Bend cotter pin ends to sit perfectly against lever.

#### **WARNING**

Whenever replacing centrifugal levers, always replace all 3 at the same time. Otherwise, drive pulley misbalancing will occur because of levers difference.



1. Head on top  
2. All on the same side

**CAUTION:** Lever assemblies must be installed so that cotter pins are on the same side.

Torque nuts to 12 N•m (106 lbf•in).


**CAUTION:** Lever ass'y and rollers must move easily after installation.

### 5,6,18,19, Fixed Half, Sliding Half, Spring, Spring Cover and Screw

To install spring cover, use spring compressor (P/N 529 035 524).

Assemble fixed and sliding halves. Note that fixed halves have different cone angle. Match cone angle with crankshaft.

Lift sliding half against spring cover and align spring cover arrow with sliding half mark.




1. Align

Install and torque screws to 13 N•m (115 lbf•in).

### 6,25,29, Sliding Half, Slider Shoe and Governor Cup


To install governor cup, use following tool:



Insert spring and slider shoes into governor cup so that groove in each slider shoe is vertical to properly slide in guides.


**CAUTION:** Make sure O-rings are installed on slider shoes and their grooves are positioned vertically.

Install fork (P/N 529 005 500) into slider shoe grooves to maintain them for governor cup installation. Proceed on 3 set of slider shoes.



Make sure to align governor cup arrow with sliding half and fixed half mark.

**NOTE:** If fixed half has no mark, align governor cup mark with segment no. 1 of inner half. Segments are identified on engine side.



1. Align

Carefully slide governor cup into sliding half. Align mark of governor cup with mark of fixed half.

Remove forks and push governor cup so that its splines engage with fixed half shaft splines.

**CAUTION:** Make sure splines of both parts are fully engaged.

## INSTALLATION

### **⚠ WARNING**

Do not apply anti-seize or any lubricant on crankshaft and drive pulley tapers.

### **⚠ WARNING**

Never use any type of impact wrench at drive pulley removal and installation.

Clean mounting surfaces as described in **CLEANING** above.

### Drive Pulley Ass'y

The installation procedure must be strictly adhered to as follows.

Install drive pulley on crankshaft extension.

Install conical washer with its concave side towards drive pulley then install screw.

### **⚠ WARNING**

Never substitute conical washer and/or screw with jobber ones. Always use Bombardier genuine parts for this particular case.

Use holder. See **REMOVAL** procedure.

Torque screw to 80 to 100 N•m (59 to 74 lbf•ft).

Install drive belt and guard.

Raise and block the rear of the vehicle and support it with a mechanical stand.

### **⚠ WARNING**

Ensure that the track is free of particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure nobody is standing near the vehicle.

Accelerate the vehicle at low speed (maximum 30 km/h (20 MPH) and apply the brake, repeat 5 times.

Recheck the torque of 80 to 100 N•m (59 to 74 lbf•ft).

### **⚠ WARNING**

After 10 hours of operation the transmission system of the vehicle must be inspected to ensure the retaining screw is properly torqued.

## Section 05 TRANSMISSION

### Subsection 03 (DRIVE PULLEY)

## DRIVE PULLEY ADJUSTMENT

The drive pulley is factory calibrated to transmit maximum engine power at a predefined RPM. Factors such as ambient temperature, altitude or surface condition may vary this critical engine RPM thus affecting snowmobile efficiency.

This adjustable drive pulley allows setting maximum engine RPM in the vehicle to maintain maximum power.

Calibration screws should be adjusted so that actual maximum engine RPM in vehicle matches with the maximum horsepower RPM given in TECHNICAL DATA 10.


**NOTE:** Use precision digital tachometer for engine RPM adjustment.

**NOTE:** The adjustment has an effect on high RPM only.

To adjust, modify ramp end position by turning calibration screws.

### 26,28,29, Calibration Screw, Locking Nut and Governor Cup


Calibration screw has a notch on top of its head.



1. Notch

Governor cup has 6 positions numbered 2 to 6. Note that in position 1 there is no stamped number (due to its location on casting).

See TECHNICAL DATA 10 for original setting.



1. Position 1 (not numbered)

Each number modifies maximum engine RPM by about 200 RPM.

Lower numbers decrease engine RPM in steps of 200 RPM and higher numbers increase it in steps of 200 RPM.

Example:


Calibration screw is set at position 3 and is changed to position 5. So maximum engine RPM is increased by about 400 RPM.

**To Adjust:**

Just loosen locking nut enough to pull calibration screw **partially** out and adjust to desired position. Do not completely remove the locking nut. Torque locking nuts to 10 N•m (89 lbf•in).

**CAUTION:** Do not completely remove calibration screw otherwise its inside washer will fall off.


**CAUTION:** Always adjust all 3 calibration screws and make sure they are all set at the same number.



1. Loosen just enough to permit rotating of calibration screw

# DRIVEN PULLEY

*Formula Type on Formula III 800 and Mach Z*



## Section 05 TRANSMISSION

### Subsection 04 (DRIVEN PULLEY)


## REMOVAL

Remove guard and drive belt from vehicle.

Remove cap screw **no. 12** and shouldered washer **no. 11** then pull the driven pulley from the countershaft.

Note shouldered washer position for reinstallation.

Take care not to loose spacer **no. 2**.



1. Spacer
2. Shoulder on this side

## 1, Countershaft

Should countershaft **no. 1** removal be required, refer to BRAKE 05-06 then look for **Countershaft and Brake Disc Removal**.

## DISASSEMBLY

Use spring compressor (P/N 529 018 600).



Remove snap ring **no. 3** and washer **no. 4** to disassemble the cam and the 2 pulley halves.

## ⚠ WARNING

Driven pulley cam is spring loaded, use above mentioned tool.

## CLEANING

### 9,10, Large Bushing and Small Bushing

During break-in period (about 10 hours of use), teflon from bushing moves to cam or shaft surface. A teflon over teflon running condition occurs, leading to low friction. So it is normal to see gray teflon deposit on cam or shaft. Do not remove that deposit, it is not dust.

When a dust deposit has to be removed from the cam or the shaft, use dry cloth to avoid removing transferred teflon.

### Pulley Half Cleaning

Use Parts Cleaner (P/N 413 711 809).

## INSPECTION

### 9,10, Bushings

Check for cracks, scratch and for free movement when assembled to fixed half.

Using a dial bore gauge measure bushing diameter. Measuring point must be at least 5 mm (1/4 in) from bushing edge.




Replace bushing(s) if worn more than specified.

DRIVEN PULLEY BUSHING WEAR LIMIT	
mm (in)	
Small bushing	38.30 (1.508)
Large bushing	89.15 (3.510)

## 6, Slider Shoe

Check cam slider shoes for wear. Replace when inside edge of cam slider shoe slope base is worn to 1 mm (.039 in) or less.



1. Measure thickness of slope base here
2. Sliding pulley side
3. Slope base

## ASSEMBLY

### 6, Cam Slider Shoe

When replacing slider shoes, always install a new set (3 shoes) to maintain equal pressure on the cam.

Assemble driven pulley components by reversing the disassembly procedure.

### 5, Cam

Coat cam interior with anti-seize lubricant.

## INSTALLATION

### 1, Countershaft

**CAUTION:** Always apply anti-seize lubricant (P/N 413 701 000) on the countershaft before final pulley installation.

Should installation procedure be required, refer to BRAKE 05-06 then look for **Brake Disc and Countershaft Bearing Adjustment**.

Reinstall the pulley on the countershaft by reversing the removal procedure.

Driven pulley end-play is 0 (zero).

## 12, Pulley Retaining Screw

Torque to 22 N•m (16 lbf•ft).

## ADJUSTMENT

Refer to PULLEY DISTANCE AND ALIGNMENT 05-05 to adjust pulley distance. Adjust drive belt height in driven pulley to obtain specified belt deflection. Turn Allen screws **no. 10** equally accordingly.

## 7, Spring

### General

It is usual to experience spring setting during breaking period of a new spring. The factory spring preload is slightly higher (about 1 kg (2 lb)) to compensate for spring setting. Specifications in TECHNICAL DATA 10 are applicable after break-in period (about 10 hours of use).

### Spring Torsional Pre-Load

To check spring pre-load adjustment, use spring scale hook (P/N 529 006 500) and a spring scale.

Remove drive belt.

Install the hook on the sliding half. Preventing fixed half from turning, pull sliding half with the spring scale perpendicularly with pulley axle.

Take 1st measurement when sliding half begins to turn. Rotate sliding half to 10 mm (3/8 in) of rotation. Hold fish scale at this position. Slowly release tension from fish scale and take 2nd measurement when sliding half begins to return. Spring pre-load is the average measurement between these 2.


$$\frac{\begin{matrix} 1^{\text{st}} \\ \text{measurement} \\ \text{(when opening)} \end{matrix} + \begin{matrix} 2^{\text{nd}} \\ \text{measurement} \\ \text{(when closing)} \end{matrix}}{2} = \text{Spring pre-load}$$

$$\text{Example: } \frac{\begin{matrix} 3.8 \text{ kg (8.4 lb)} \\ \text{(when opening)} \end{matrix} + \begin{matrix} 3.4 \text{ kg (7.5 lb)} \\ \text{(when closing)} \end{matrix}}{2} = \begin{matrix} 3.6 \text{ kg} \\ \text{(8 lb)} \\ \text{Actual spring} \\ \text{pre-load} \end{matrix}$$



## Section 05 TRANSMISSION

### Subsection 04 (DRIVEN PULLEY)




#### TYPICAL

Step 1: 1<sup>st</sup> measurement

Step 2: 2<sup>nd</sup> measurement

To adjust spring pre-load, relocate spring end in cam, moving it clockwise to increase the pre-load and counterclockwise to decrease it. Refer to TECHNICAL DATA 10.

**NOTE:** If spring pre-load can not be adjusted, try to relocate the other end of spring in sliding pulley (holes A, B and C).



#### TYPICAL

Letters and numbers shown in illustration are actual letters and numbers embossed on parts

**NOTE:** Always recheck torsional pre-load after adjusting.

## Pulley Alignment and Drive Belt Deflection


Refer to PULLEY DISTANCE AND ALIGNMENT 05-05 and DRIVE BELT 05-02 to perform adjustments.

**CAUTION:** Drive belt and pulley adjustments must always be checked whenever pulleys have been removed, replaced or disassembled.

## 5, Cam

Make sure to install proper cam. Refer to TECHNICAL DATA 10.


Cam angle is identified on cam.



**NOTE:** For high altitude regions, the *High Altitude and Sea Level Technical Data Booklet* (P/N 484 200 019 and 484 054 500 for binder) gives information about calibration according to altitude.

**Section 05 TRANSMISSION**  
Subsection 04 (DRIVEN PULLEY)

HPV27 on Formula III 700 R, Mach 1 R, Mach Z R and Grand Touring 700/SE



## Section 05 TRANSMISSION

### Subsection 04 (DRIVEN PULLEY)


## REMOVAL

Remove guard and drive belt from vehicle.

Remove cap screw **no. 1** and shouldered washer **no. 13** then pull the driven pulley from the countershaft.

Note shouldered washer position for reinstallation.

Take care not to loose spacer **no. 4**.




1. Spacer
2. Shoulder on this side
3. Concave side facing driven pulley

## 5, Countershaft

Should countershaft **no. 5** removal be required, refer to BRAKE 05-06 then look for **Countershaft and Brake Disc Removal**.

## DISASSEMBLY

Use spring compressor (P/N 529 035 524).



Remove half keys **no. 6** and washer **no. 7** to disassemble the cam and the 2 pulley halves.

## ⚠ WARNING

Driven pulley cam is spring loaded, use above mentioned tool.

## CLEANING

### 8,9, Large Bushing and Small Bushing

During break-in period (about 10 hours of use), teflon from bushing moves to cam or shaft surface. A teflon over teflon running condition occurs, leading to low friction. So it is normal to see gray teflon deposit on cam or shaft. Do not remove that deposit, it is not dust.

When a dust deposit has to be removed from the cam or the shaft, use dry cloth to avoid removing transferred teflon.


### Pulley Half Cleaning

Use Parts Cleaner (P/N 413 711 809).

## INSPECTION

### 10, Slider Shoe

Check cam slider shoes for wear. Replace when inside edge of cam slider shoe slope base is worn to 1 mm (.039 in) or less.




1. Measure thickness of slope base here
2. Sliding pulley side
3. Slope base

## ASSEMBLY

### 10, Cam Slider Shoe

When replacing slider shoes, always install a new set (3 shoes) to maintain equal pressure on the cam.

Install slider shoes as per following photo. Red slider shoes are being used for reverse and black ones for forward.



1. BLACK slider shoe
2. RED slider shoe

## 12, Screws

These screws are machined at there end. With the adjustment ring steel to position 0 (zero), screw ends are flush with inner side of fixed pulley half when tighten.

**CAUTION:** If any of these screws is not flush with inner side of sliding pulley, bushings will worn unequally.

Assemble driven pulley components by reversing the disassembly procedure.

## 11, Cam

Coat cam interior with anti-seize lubricant.

## INSTALLATION

### 5, Countershaft

**CAUTION:** Always apply anti-seize lubricant (P/N 413 701 000) on the countershaft before final pulley installation.

Should installation procedure be required, refer to BRAKE 05-06 then look for **Brake Disc and Countershaft Bearing Adjustment**.

Reinstall the pulley on the countershaft by reversing the removal procedure.

Driven pulley end-play is 0 (zero).

### 1, Pulley Retaining Screw

Torque to 22 N•m (16 lbf•ft).

## ADJUSTMENT

Refer to PULLEY DISTANCE AND ALIGNMENT 05-05 to adjust pulley distance. Adjust drive belt height in driven pulley to obtain specified belt deflection. Loosen screws no. 12, turn adjustment ring then retighten screws.

## Pulley Alignment and Drive Belt Deflection


Refer to PULLEY DISTANCE AND ALIGNMENT 05-05 and DRIVE BELT 05-02 to perform adjustments.

**CAUTION:** Drive belt and pulley adjustments must always be checked whenever pulleys have been removed, replaced or disassembled.

## 11, Cam

Make sure to install proper cam. Refer to TECHNICAL DATA 10.

Cam angle is identified on cam.



**NOTE:** For high altitude regions, the *High Altitude and Sea Level Technical Data Booklet* (P/N 484 200 019 and 484 054 500 for binder) gives information about calibration according to altitude.

# PULLEY DISTANCE AND ALIGNMENT

## GENERAL

The pulley distance we will refer to in this section, is the space separating the drive and driven pulley outside diameters (Z measurement).

This basic distance is provided as an assembly guide and indicates the dimensions between which satisfactory belt deflection will be obtained.

Both pulley distance adjustment and pulley alignment must be carried out to ensure the highest efficiency of the transmission system. Furthermore, optimum drive belt operation and minimal wear will be obtained only with proper pulley alignment.

**CAUTION:** Before checking pulley adjustment, the rear suspension must be mounted on the vehicle and track tension/alignment must be done. Always check pulley adjustment after suspension is adjusted.

### WARNING

Failure to correctly perform pulley alignment may cause the vehicle to creep forward at idle.

All Pulley Alignment Specifications Refer to:

X = Distance between straight bar and drive pulley fixed half edge, **measured between pulleys.**

Y = Distance between straight bar and drive pulley fixed half edge, **measured at the end of straight bar.**

Z = Distance between outside diameter of pulleys.

## GENERAL PROCEDURE


Remove guard and drive belt.

By turning and pushing the sliding half, open the driven pulley. Insert a straight bar 9.5 mm (.375 in) square, 48 cm (19 in) long or the proper alignment template into the opened driven pulley.

## Measuring Procedure

### Using Straight Bar

Always measure distances X and Y from the farther straight bar side (including its thickness to the fixed half edge).



TYPICAL

1. Straight bar
2. Front of vehicle

The distance Y **must** exceed distance X to compensate for the twist due to the engine torque.

## Drive Belt Deflection

**NOTE:** When pulley distance and alignment are adjusted to specifications, refer to DRIVE BELT 05-02 to adjust drive belt deflection.


**CAUTION:** This section deals mainly with adjustment procedures. For complete assembly requirements, refer to the proper ENGINE or TRANSMISSION installation section.

## Section 05 TRANSMISSION

### Subsection 05 (PULLEY DISTANCE AND ALIGNMENT)

## PULLEY ALIGNMENT AND DISTANCE SPECIFICATIONS CHART

MODELS	PULLEY DISTANCE		OFFSET	
	Z	X	Y-X	
	± 0.50 mm (± .020 in)	± 0.50 mm (± .020 in)	± 0.5 mm (± .020 in)	
Models with Formula type driven pulley	120.0 (4.724)	35.5 (1.398)	1.5 (0.060)	
Models with HPV27 type driven pulley	121.0 (4.764)	35.5 (1.398)	1.5 (0.060)	



#### TYPICAL

1. Engine movement
2. Contact

**NOTE:** Prior to performing pulley adjustment, loosen torque rod nut to allow engine movement. Engine supports have tendency to stick to frame, work engine loose prior to aligning.

### Pulley Distance Adjustment Method

#### Engine Movement


The engine support has slotted mounting holes. Move engine to obtain specified distance between pulleys.

### Pulley Alignment Method


#### Engine Movement

Loosen the 4 bolts retaining engine support to the frame. Position engine to obtain the specified alignment.

**NOTE:** After alignment, adjust torque rod so it slightly contacts stopper plate. Do not over tighten, it will disalign pulleys.




1. Retighten



1. Loosen

# BRAKE

## HYDRAULIC DISC BRAKE



## Section 05 TRANSMISSION

### Subsection 06 (BRAKE)

## REMOVAL

### BRAKE DISC REMOVAL

Brake disc can be withdrawn without removing caliper. Proceed as follows:

- Remove belt guard, belt and driven pulley.
- Remove air silencer.
- Unbolt bearing support **no. 4** from chassis.
- Unbolt caliper from chaincase.
- Open chaincase and remove upper sprocket.
- Pull countershaft **no. 3** toward driven pulley side to free from chaincase and disc.
- Remove disc.

## DISASSEMBLY

Only brake pads are available as spare parts. If caliper or master cylinder are damaged, replace each of them as an assembly.

## CLEANING

Clean all metal components in a general purpose solvent. Thoroughly dry all components before assembling.


**CAUTION:** Do not clean brake pads in solvent. Soiled brake pads must be replaced by new ones.

## INSPECTION

### 1, Brake Pad

Brake pads must be replaced when lining is 1 mm (1/32 in) thick or less.

**CAUTION:** Brake pads must always be replaced in pairs.



#### TYPICAL

1. Fixed pad
2. Inner caliper
- A. 1 mm (1/32 in) minimum

### 2, Brake Disc

Check for scoring, cracking or bending, replace as required.

**CAUTION:** Brake disc should never be machined.

#### **⚠ WARNING**

Always install a new nut when servicing.

## INSTALLATION

To install brake, reverse removal procedure paying attention to the following.

#### **⚠ WARNING**

Avoid getting oil on brake pads.

### 2, Brake Disc

Apply anti-seize lubricant (P/N 413 701 000) on shaft.

The disc hub exceeds the disc more from one side than from the other. Install disc with the longer exceeding portion toward driven pulley.



## ADJUSTMENT

### Countershaft Bearing

Insert countershaft (with brake disc) from chaincase side through countershaft support (driven pulley side), then insert into chaincase.

Install countershaft bearing **no. 4** and ensure that countershaft is properly aligned, then tighten 3 retaining screws.

Torque castellated nut of upper sprocket to 60 N•m (44 lbf•ft).

**CAUTION:** Upper sprocket castellated nut must be tightened **before** bolting bearing support.

Close chaincase.

### 5, Brake Light

There is no adjustment on these models. Check that switch is securely installed.

## BLEEDING

Change brake fluid once a year.

Bleed brake system as follows:

Keep sufficient DOT 4 brake fluid in reservoir at all times.


**CAUTION:** Use only DOT 4 brake fluid.

Install a hose on left side bleeder. Route this hose to a container.

Pump a few times brake lever and while holding brake lever depressed, open left side bleeder and check for air to escape.

Repeat with the same bleeder until no air appears in hose.


Proceed the same way with the right side bleeder.



#### TYPICAL

1. Open bleeder
2. Clear hose to catch used brake fluid

# CHAINCASE



## Section 05 TRANSMISSION

### Subsection 07 (CHAINCASE)

## REMOVAL

To remove chaincase proceed as follows.

Remove tuned pipes and muffler.

### **⚠ WARNING**

Never remove exhaust components when engine is hot.

Remove hair pin no. 8. Release drive chain tension by unscrewing tensioner adjustment screw.

Drain oil by removing chaincase cover no. 2.

### **3,4,5,6,13,16,17, Cotter Pin, Nut, Sprocket, Shim and Drive Chain**

Apply parking brake.

Remove cotter pin no. 3 and nut no. 4 retaining upper sprocket no. 5 and screw no. 15 retaining lower sprocket no. 16. Pull sprockets and drive chain simultaneously. Remove shims nos. 6 and 17.


**NOTE:** Should countershaft removal be required, refer to BRAKE 05-06 then look for **Countershaft Removal**.

Release parking brake.

Remove 3 nuts no. 14.

Unfold locking tab no. 23 then remove caliper retaining screws no. 22.

Release track tension, use drive axle holder no. 20 (P/N 529 007 200).



#### TYPICAL

1. Drive axle
2. Suspension cross shaft

Pry out drive axle oil seal no. 19 from chaincase.

Pull chaincase from drive axle and countershaft.

Using 2 large screwdrivers inserted between chaincase no. 7 and frame, pry complete assembly from vehicle.

## INSPECTION

Visually inspect the chain for cracked, damaged or missing links. Check for worn or defective bearings, sprockets and chain tensioner components.

### **⚠ WARNING**

If chain deflection is greater than 38 mm (1.5 in) (without chain tensioner), replace chain and check condition of sprockets.

## GEAR RATIO MODIFICATION

For particular applications, the number of teeth of the sprockets can be increased or decreased on lower and upper sprockets.

Refer to TECHNICAL DATA 10 for gear ratios.

**CAUTION:** Gear ratio modifications should only be performed by experienced mechanics since they can greatly affect vehicle performance.

**NOTE:** For high altitude regions, the *High Altitude and Sea Level Technical Booklet* (P/N 484 200 019 and P/N 484 054 500 for binder) gives information about calibration according to altitude.

## INSTALLATION

Reverse removal procedure and pay attention to the following. Replace oil seals, gaskets and O-rings.

### 11, Oil Seal

Using an appropriate pusher, press the oil seal into chaincase hub. Oil seal must fit flush with the chaincase edge.

**NOTE:** Should installation procedure for countershaft be required, refer to BRAKE 05-06.

### 5,16, Sprockets

Position the sprockets with the writing facing the chaincase cover. Sprocket hub faces toward chaincase.


### 4, Upper Sprocket Castellated Nut

Torque to 45 to 75 N•m (33 to 55 lbf•ft).

Install new cotter pin in the position shown.

**CAUTION:** When removing a cotter pin always replace with a new one.

**CAUTION:** Cotter pin will rub on chaincase cover if installed otherwise.



1. New
2. Fold cotter pin over castellated nut flats only

### 18, Circlip

**CAUTION:** It is of the utmost importance to install the circlip otherwise damage to the chaincase components may occur.

## DRIVE CHAIN ADJUSTMENT

**NOTE:** Brake disc key must be in good condition before checking chain free play.

### 10, O-Ring

Replace O-ring **no. 10** on tensioner adjustment screw. Fully tighten tensioner adjustment screw **by hand**, then back off only far enough for hair pin to engage in locking hole.

This initial adjustment should provide 3-5 mm (1/8-13/64 in) free-play when measured at the outer circumference of the brake disc.

**CAUTION:** Free-play must not exceed 5 mm (13/64 in), readjust if necessary.

### **⚠ WARNING**


If the specified free-play is not reached with the tensioner screw fully tightened, replace chain and check the condition of sprockets.

### 21, Chaincase Oil

Pour 250 mL (8.5 U.S. oz) of synthetic chaincase oil (P/N 413 803 300) into chaincase.

**NOTE:** Chaincase oil capacity is 250 mL (8.5 U.S. oz).

Check oil level with the dipstick then add if required. Remove metal particles from magnet.



#### TYPICAL

1. Dipstick
2. Oil level
3. Level between marks

**NOTE:** Chaincase must be in its proper position when checking oil level.

## ADJUSTMENT

### Pulley Alignment

Refer to PULLEY DISTANCE AND ALIGNMENT 05-05.

### Track Tension and Alignment

Refer to TRACK 07-04.

# DRIVE CHAIN

## SILENT CHAIN

All CK3 models are equipped with a 13-plates wide silent chain. Fit chain on sprockets to make sure that you are using right ones according to width. Refer to TECHNICAL DATA 10.

**NOTE:** No work (separation, lengthening) can be done on the silent chain type.