

# TABLE OF CONTENTS

---

<b>ENGINE .....</b>	<b>03-02-1</b>
ENGINE LEAK VERIFICATION FLOW CHART .....	03-02-12
<hr/>	
<b>FUEL AND OIL SYSTEMS .....</b>	<b>03-03-1</b>
<hr/>	
<b>TRANSMISSION AND BRAKE SYSTEMS .....</b>	<b>03-04-1</b>
<b>TRANSMISSION .....</b>	<b>03-04-1</b>
<b>BRAKE SYSTEM .....</b>	<b>03-04-8</b>
HYDRAULIC BRAKE .....	03-04-8
<hr/>	
<b>ELECTRICAL SYSTEM.....</b>	<b>03-05-1</b>
<hr/>	
<b>SUSPENSION AND TRACK .....</b>	<b>03-06-1</b>

# ENGINE

The following chart is provided to help diagnose the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

<b>SYMPTOM</b>	<b>ENGINE BACKFIRES.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check spark plugs.</b> a. Carbon accumulation caused by defective spark plug(s). <i>Clean carbon accumulation from piston and cylinder head and install dry properly gapped spark plug(s).</i>
	<b>2. Check ignition timing.</b> a. Timing is too advanced. <i>Set timing according to specifications (refer to TECHNICAL DATA).</i>
	<b>3. Check carburetor.</b> a. Fuel passages obstructed. <i>Clean carburetor and install new filter(s).</i> b. Fuel level too low. <i>Adjust float level according to specifications.</i>
	<b>4. Check cooling system.</b> a. Low coolant level. <i>Adjust coolant level. Proceed with a leakage test (refer to LIQUID COOLING SYSTEM) and repair as required.</i> b. Defective tank cap. <i>Replace cap.</i> c. Defective thermostat. <i>Replace thermostat.</i> d. Air in system. <i>Bleed system.</i>

<b>SYMPTOM</b>	<b>ENGINE SUDDENLY TURNS OFF AT HIGH RPM AND/OR WITH LIGHT LOAD.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check that all 3 ground wires are well connected.</b>

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

SYMPTOM	ENGINE SUDDENLY TURNS OFF.
CONDITION	NORMAL USE.
TEST/INSPECTION	<b>1. Perform engine leak test. Refer to ENGINE LEAK VERIFICATION FLOW CHART. Check possible piston seizure.</b> a. Damaged gasket and/or seal. <i>Replace defective parts.</i>
	<b>2. "Four-corner" seizure of piston(s).</b> a. High acceleration when engine is cold. Piston expands faster than cylinder. <i>Replace piston(s). Ask driver to refer to the WARM-UP PROCEDURE in the Operator's Guide.</i>
	<b>3. Piston(s) seizure on exhaust side (color on piston dome is correct).</b> a. Kinked fuel tank vent tube. <i>Relocate fuel tank vent tube.</i> b. Leaks at fuel line connections or damaged fuel lines. <i>Replace defective lines.</i> c. Fuel does not flow through carburetor(s) (foreign particles in needle area and/or varnish formation in carburetor(s)). <i>Clean carburetor(s) and install new filter(s).</i> d. Spark plug heat range is too warm. <i>Install spark plugs with appropriate heat range (refer to TECHNICAL DATA).</i> e. Improper ignition timing. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i> f. Restriction in exhaust system. <i>Replace.</i> g. Compression ratio is too high. <i>Install genuine parts.</i> h. Carburetor calibration is too lean. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i> i. Improper reed valve adjustment or damage. <i>Adjust according to specifications (refer to 493, 593, 693 AND 793 ENGINES TYPES) and/or install Bombardier's recommended reed valve.</i> j. Poor quality oil. <i>Use BOMBARDIER injection oil.</i> k. Leaks at air intake silencer. <i>Replace air intake silencer grommets.</i>
	<b>4. Melted and/or perforated piston dome; melted section at ring end gap.</b> a. When piston reaches TDC, mixture is ignited by heated areas in combustion chamber. This is due to an incomplete combustion of a poor quality oil. <i>Clean residue accumulation in combustion chamber and replace piston(s). Use BOMBARDIER injection oil.</i> b. Spark plug heat range is too high. <i>Install recommended dry properly gapped spark plugs (refer to TECHNICAL DATA).</i> c. Ignition timing is too advanced. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i> d. Inadequate fuel quality. <i>Use appropriate fuel.</i> e. Carburetion is too lean. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i>

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

	<p><b>5. Seized piston all around the circumference (dry surface).</b></p> <p>a. Lack of oil, damaged oil line or defective injection pump. <i>Replace defective part(s).</i></p>
	<p><b>6. Grooves on intake side of piston only.</b></p> <p>a. Oil film eliminated by water (snow infiltration in engine). This can also be caused by running engine on choke for too long. Excessive fuel will remove the oil film on the piston and make marks. <i>Replace piston(s) and check if intake system leaks.</i></p>
	<p><b>7. Piston color is dark due to seizure on intake and exhaust sides.</b></p> <p>a. Cooling system leaks and lowers coolant level. <i>Proceed with a leakage test (refer to LIQUID COOLING SYSTEM) and repair as required. Add coolant in cooling system until appropriate level is reached.</i></p> <p>b. Accumulation of foreign particles in needle valve and/or main jet area. <i>Clean carburetor(s).</i></p>
	<p><b>8. Cracked or broken piston(s).</b></p> <p>a. Cracked or broken piston(s) due to excessive piston/cylinder clearance or engine overrevving. <i>Replace piston(s). Check piston/cylinder clearance (refer to TECHNICAL DATA). Adjust drive pulley according to specifications (refer to TECHNICAL DATA) and/or clean pulley sheaves if they are contaminated with greasy particles.</i></p>
	<p><b>9. DPM manifold air vent is obstructed.</b></p> <p>a. Carburetion is too lean. <i>Ensure proper air vent.</i></p>

<b>SYMPTOM</b>	<b>PISTON RING AND CYLINDER SURFACES ARE SCRATCHED.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check oil quality.</b></p> <p>a. Poor quality oil. <i>Use BOMBARDIER injection oil.</i></p>
	<p><b>2. Check injection pump and its hoses.</b></p> <p>a. Inadequate injection pump adjustment and/or defective hoses. <i>Adjust pump according to specifications (refer to ENGINE) and/or replace hoses.</i></p>

<b>SYMPTOM</b>	<b>ENGINE DOES NOT OFFER MAXIMUM POWER AND/OR DOES NOT REACH MAXIMUM OPERATING RPM.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check spark plug condition and gap.</b></p> <p>a. Fouled spark plugs or wrong spark plug gap. <i>Install new properly gapped spark plugs.</i></p>
	<p><b>2. Check if there is water in fuel.</b></p> <p>a. There is water in fuel. <i>Drain fuel system, then fill with appropriate fuel.</i></p>
	<p><b>3. Check items listed in ENGINE RUNS OUT OF FUEL (refer to FUEL AND OIL SYSTEM subsection).</b></p>

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

	<p><b>4. Check carburetor adjustments and cleanliness.</b></p> <p>a. Inadequate carburetor adjustments or dirt accumulation. <i>Adjust according to specifications (refer to TECHNICAL DATA) or clean.</i></p>
	<p><b>5. Check drive belt.</b></p> <p>a. Worn belt. <i>Replace belt if width is 3 mm (1/8 in) less than nominal dimension (refer to TECHNICAL DATA).</i></p>
	<p><b>6. Check track adjustment.</b></p> <p>a. Too much tension and/or improper alignment. <i>Align track and adjust its tension to specifications (refer to TECHNICAL DATA).</i></p>
	<p><b>7. Check drive pulley.</b></p> <p>a. Improper calibration screw adjustments (TRA pulley) and/or worn bushing(s). <i>Adjust according to specifications (refer to TECHNICAL DATA) and/or replace bushing(s).</i></p>
	<p><b>8. Check driven pulley.</b></p> <p>a. Worn bushing and/or spring tension. <i>Replace spring and/or adjust its tension according to specifications (refer to TECHNICAL DATA).</i></p>
	<p><b>9. Check exhaust system.</b></p> <p>a. Restriction or exhaust system leakage. <i>Replace damaged parts and/or reseal with Ultra Copper (refer to 593 HO and 793 ENGINE TYPES).</i></p>
	<p><b>10. Check ignition timing.</b></p> <p>a. Decrease in power due to delayed ignition. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i></p>
	<p><b>11. Check engine compression.</b></p> <p>a. Worn piston(s) and ring(s). <i>Replace (refer to TECHNICAL DATA for specifications).</i></p>
	<p><b>12. Check engine cooling system.</b></p> <p>a. Coolant level is low, cap fails to pressurize system or air circulates through lines. <i>Adjust level, replace cap or bleed cooling system.</i></p>
	<p><b>13. Check reed valve.</b></p> <p>a. Improper tightness and/or opening. <i>Replace or adjust. Refer to proper ENGINE subsection.</i></p>

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

<b>SYMPTOM</b>	<b>ENGINE DETONATION AT MAXIMUM RPM.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check which type of fuel is used.</b> a. Octane number is too low and/or alcohol level is too high. <i>Use recommended fuel type.</i>
	<b>2. Check spark plug type.</b> a. Improper spark plug heat range. <i>Install recommended spark plugs (refer to TECHNICAL DATA).</i>
	<b>3. Check exhaust system.</b> a. Too much restriction. <i>Replace.</i>
	<b>4. Check ignition timing.</b> a. Timing is too advanced. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i>
	<b>5. Check carburetion.</b> a. Fouled and/or improper carburetor components. <i>Clean or replace according to specifications (refer to TECHNICAL DATA).</i>
	<b>6. Check compression ratio and combustion chamber volume.</b> a. Compression ratio is too high. <i>Install genuine parts.</i>

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

<b>SYMPTOM</b>	<b>ENGINE TURNS OVER BUT FAILS TO START.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check switches.</b> a. Ignition switch, emergency cut-out switch or tether switch is OFF. <i>Place all switches in the RUN or ON position. If it still does not work, connect DESS switch BK/GN and BK/WH wires together (harness side).</i>
	<b>2. Check starting procedure in <i>Operator's Guide</i>.</b> a. Mixture too lean. <i>Use choke as described in Operator's Guide.</i> a. Mixture too rich. <i>Do not overchoke or use choke with a warm engine. Use choke as described in Operator's Guide.</i>
	<b>3. Check amount of fuel on spark plug.</b> a. Flooded engine (spark plug wet when removed). <i>Do not overprime or overchoke. Remove wet spark plugs, turn ignition switch to OFF and crank engine several times. Install clean dry properly gapped spark plugs. Start engine following usual starting procedure.</i>
	<b>4. Check fuel lines.</b> a. No fuel to the engine (spark plugs dry when removed). <i>Check fuel tank level; turn fuel valve on if applicable; check fuel filter, replace if clogged; check condition of fuel and impulse lines and their connections.</i>
	<b>5. Check engine compression.</b> a. Insufficient engine compression. <i>Replace defective part(s) (ex.: piston(s), ring(s), etc.).</i>

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

<b>SYMPTOM</b>	<b>IRREGULAR ENGINE IDLE.</b>
<b>CONDITION</b>	NORMAL USE AFTER ENGINE WARM UP.
<b>TEST/INSPECTION</b>	<p><b>1. Check choke.</b> a. Choke plunger may be partially opened. <i>Readjust.</i></p> <p><b>2. Check carburetor adapter.</b> a. Air enters through a crack. <i>Replace.</i></p> <p><b>3. Check air screw position.</b> a. Inadequate fuel/air mixture. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i></p> <p><b>4. Check dimension of pilot jet.</b> a. Inadequate fuel/air mixture. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i></p> <p><b>5. Check reed valve.</b> a. Improper tightness and/or opening. <i>Replace or adjust. Refer to proper ENGINE subsection.</i></p> <p><b>6. Perform engine leak test.</b> a. Leaking gaskets allow air to enter in engine. <i>Replace defective parts.</i></p> <p><b>7. DPM manifold air vent is obstructed.</b> a. Carburetion is too lean. <i>Ensure proper air vent.</i></p>

<b>SYMPTOM</b>	<b>HIGH ENGINE OPERATING TEMPERATURE</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check temperature gauge sensor.</b> a. False reading. <i>Check terminal connections. If problem persists, replace sensor.</i></p> <p><b>2. Check snow deflector.</b> a. No snow deflector at rear of tunnel. <i>Install the snow deflector.</i></p> <p><b>3. Check coolant level and check if there is air infiltration in the system or if there are leaks in gasket areas.</b> a. Low coolant level or air in system. Add coolant until recommended level is reached, bleed system and/or tighten clamps. Proceed with a leakage test (refer to LIQUID COOLING SYSTEM) and repair as required.</p> <p><b>4. Check if coolant flows through system properly.</b> a. Foreign particles and/or broken coolant pump impeller. <i>Clean cooling system and/or replace coolant pump impeller.</i></p>



---

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

---

	<p><b>5. Check thermostat.</b></p> <p>a. Thermostat reacts slowly or not at all. <i>Replace.</i></p>
	<p><b>6. Check antifreeze concentration.</b></p> <p>a. Antifreeze concentration is too high. <i>Adjust concentration according to Bombardier's recommendations.</i></p>
	<p><b>7. Check tank cap.</b></p> <p>a. Cap does not hold pressure. <i>Replace.</i></p>
	<p><b>8. Check carburetion.</b></p> <p>a. Improperly adjusted or inadequate carburetor components. <i>Adjust according to specifications (refer to TECHNICAL DATA) or replace inadequate component(s).</i></p>
	<p><b>9. Check cylinder head gaskets.</b></p> <p>a. Worn gaskets. <i>Replace.</i></p>
	<p><b>10. Check ignition timing.</b></p> <p>a. Ignition timing is too advanced. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i></p>
	<p><b>11. Check if there are leaks at air intake silencer and/or engine crankcase.</b></p> <p>a. Leak(s). <i>Repair or replace.</i></p>
	<p><b>12. Check condition and heat range of spark plugs.</b></p> <p>a. Melted spark plug tip or inadequate heat range. <i>Replace.</i></p>

**Section 03 TROUBLESHOOTING**  
Subsection 02 (ENGINE)

<b>SYMPTOM</b>	<b>ENGINE EQUIPPED WITH RAVE VALVE DOES NOT REACH ITS FULL OPERATING RPM (500 TO 1000 RPM SLOWER).</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check RAVE valve pistons.</b></p> <p>a. Valve piston(s) is (are) not screwed to the bottom. <i>Screw valve piston(s) to bottom.</i></p> <p><b>2. Check that valve moves freely.</b></p> <p>a. Valve stuck in closed position. <i>Clean.</i></p> <p><b>3. Check RAVE valve stems.</b></p> <p>a. Bent RAVE valve stem(s). <i>Replace.</i></p> <p><b>4. Check RAVE valves.</b></p> <p>a. Jammed valve(s). <i>Clean.</i></p> <p><b>5. Check tension of RAVE springs.</b></p> <p>a. Inadequate spring tension. <i>Replace.</i></p> <p><b>6. Check RAVE pressure holes.</b></p> <p>a. Clogged holes. <i>Clean.</i></p> <p><b>7. Check clamps or sleeves.</b></p> <p>a. Damaged clamp(s) or sleeve(s). <i>Replace.</i></p> <p><b>8. Check exhaust tightness.</b></p> <p>a. Exhaust system is leaking leading to a too low back pressure. <i>Replaces parts and reseal.</i></p>

<b>SYMPTOM</b>	<b>ENGINE EQUIPPED WITH RAVE. ENGINE HESITATES AT LOW OR MID-SPEED AND REACHES MAXIMUM PERFORMANCE ONLY AFTER A WHILE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check RAVE valve spring(s).</b></p> <p>a. Spring tension is too low or spring(s) is (are) broken. <i>Replace.</i></p> <p><b>2. Check RAVE valve cover red adjustment screws.</b></p> <p>a. Adjustment screw(s) is (are) too loose. <i>Adjust according to ASSEMBLY PROCEDURE in appropriate engine subsections.</i></p> <p><b>3. Check RAVE valve movement (RAVE movement indicator P/N 861 725 800).</b></p> <p>a. Valve(s) is (are) stuck in open position. <i>Clean.</i></p>

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

<b>SYMPTOM</b>	<b>REWIND STARTER ROPE DOES NOT REWIND.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check rewind spring.</b> a. Broken spring. <i>Replace spring.</i>

<b>SYMPTOM</b>	<b>REWIND STARTER PAWL DOES NOT ENGAGE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check stopper spring.</b> a. Broken stopper spring. <i>Replace.</i>
	<b>2. Check pawl and pawl lock.</b> a. Pawl and pawl lock have stuck together because of heat. <i>Replace.</i>
	<b>3. Check pawl and rope sheave.</b> a. Pawl and rope sheave have stuck together because of heat. <i>Replace.</i>

<b>SYMPTOM</b>	<b>ENGINE PINGING.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check fuel lines.</b> a. Bent fuel lines (preventing fuel from flowing through). <i>Relocate or replace fuel lines.</i>
	<b>2. Check if carburetor(s) is (are) clean.</b> a. Dirt prevents fuel from flowing through. <i>Clean.</i>
	<b>3. Check ignition timing.</b> a. Timing is too advanced. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i>
	<b>4. Check compression ratio.</b> a. Compression ratio is too high. <i>Replace inadequate part(s) to obtain manufacturer's recommended compression ratio or use a higher grade fuel.</i>


**Section 03 TROUBLESHOOTING**  
Subsection 02 (ENGINE)

<b>SYMPTOM</b>	<b>ENGINE GENERATES A LOT OF VIBRATIONS.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check engine supports and stopper.</b> a. Loose and/or broken supports or interference between support(s) and chassis. <i>Retighten to specification (refer to TECHNICAL DATA) or replace.</i>
	<b>2. Check drive pulley (refer to VIBRATIONS ORIGINATING FROM DRIVE PULLEY).</b>
	<b>3. Check carburetor synchronization.</b> a. Throttle slide height is not the same on each carburetor and/or throttle slides opening is unsynchronized. <i>Adjust throttle slide heights and throttle cable.</i>
	<b>4. Check for crankshaft and bearings.</b> a. Loose crankshaft bearings or uneven crankshaft. <i>Retighten or replace the parts.</i>

## Section 03 TROUBLESHOOTING

### Subsection 02 (ENGINE)

# ENGINE LEAK VERIFICATION FLOW CHART



# FUEL AND OIL SYSTEMS

The following chart is provided to help diagnose the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

<b>SYMPTOM</b>	<b>HIGH FUEL CONSUMPTION OR RICH MIXTURE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check fuel tank.</b></p> <p>a. Perforated fuel tank. <i>Replace fuel tank.</i></p>
	<p><b>2. Check fuel pump, reservoir and carburetor fittings.</b></p> <p>a. Leaking fittings. <i>Replace defective part.</i></p>
	<p><b>3. Check choke adjustment.</b></p> <p>a. Fuel flows through choke circuit while engine runs. <i>Readjust choke.</i></p>
	<p><b>4. Check float height in carburetor(s).</b></p> <p>a. Fuel level is too high in float bowl(s). <i>Adjust according to specifications (refer to TECHNICAL DATA).</i></p>
	<p><b>5. Check needle valve on each carburetor.</b></p> <p>a. Foreign particles prevent needle valve from closing and/or pounded seating area. <i>Clean or replace needle valve, then clean seating area.</i></p>

<b>SYMPTOM</b>	<b>FUEL LEAKS IN ENGINE BASE WHEN ENGINE IS STOPPED.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check items 3, 4 and 5 of HIGH FUEL CONSUMPTION.</b></p>
	<p><b>2. Check fuel pump diaphragm.</b></p> <p>a. Cracked diaphragm. <i>Replace.</i></p>

---

## Section 03 TROUBLESHOOTING

### Subsection 03 (FUEL AND OIL SYSTEMS)

---

<b>SYMPTOM</b>	<b>ENGINE LACKS POWER OR STALLS AT HIGH RPM.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check fuel tank vent hose.</b> a. Kinked or clogged hose. <i>Relocate or replace.</i>
	<b>2. Check fuel filter.</b> a. Clogged filter. <i>Replace.</i>
	<b>3. Check fuel lines.</b> a. Kinked or clogged lines. <i>Relocate or replace.</i>
	<b>4. Check fuel pump flow.</b> a. Check impulse hose. <i>Replace.</i> b. Dried diaphragm. <i>Replace.</i>
	<b>5. Check if carburetor(s) is (are) clean.</b> a. Varnish. <i>Clean.</i>

**Section 03 TROUBLESHOOTING**  
Subsection 03 (FUEL AND OIL SYSTEMS)

<b>SYMPTOM</b>	<b>HIGH INJECTION OIL CONSUMPTION.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check oil injection pump adjustment.</b> a. Oil injection pump adjusted too rich. <i>Adjust.</i></p> <p><b>2. Check injection pump identification.</b> a. Wrong pump. <i>Replace with the appropriate pump. Refer to OIL INJECTION SYSTEM.</i></p> <p><b>3. Check injection oil lines and their fitting.</b> a. Leaking lines and/or cover. <i>Replace defective part(s).</i></p> <p><b>4. Check injection pump cover gasket.</b> a. Broken gasket. <i>Replace.</i></p> <p><b>5. Check nipple check valve.</b> a. Check valve stuck open. <i>Replace.</i></p> <p><b>6. Check pump.</b> a. Defective pump. <i>Replace pump.</i></p> <p><b>7. Test pump shaft gear reservoir for leaks.</b> a. Leaking seal(s). <i>Replace seal(s).</i></p>



## Section 03 TROUBLESHOOTING

### Subsection 03 (FUEL AND OIL SYSTEMS)

<b>SYMPTOM</b>	<b>ENGINE LACKS FUEL (OR LEAN MIXTURE).</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check fuel filter ball located in fuel tank. Ball must move freely.</b> a. Corrosion due to oxidation at installation. <i>Replace fuel filter.</i>
	<b>2. Check if lines are perforated, kinked, or if they leak at fittings.</b> a. Lines are too big for their fittings or are improperly routed. <i>Replace or properly relocate lines.</i>
	<b>3. Check fuel pump outlet flow.</b> a. Dirt clogging fuel pump lines or torn membrane. <i>Clean or replace fuel pump.</i>
	<b>4. Check needle valve on each carburetor.</b> a. Dirt (varnish, foreign particle) clogging fuel line inlets. <i>Clean.</i>
	<b>5. Check main jet.</b> a. Dirt (varnish, foreign particle) accumulation at main jet. <i>Clean.</i>
	<b>6. Check float(s) height in carburetor bowl on each carburetor.</b> a. Lack of fuel at high speed because float height is too low. <i>Adjust float height according to specifications.</i>

<b>SYMPTOM</b>	<b>DPM SEEMS TO BE DEFECTIVE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check electrical connections.</b> a. Corroded terminals. <i>Clean or replace.</i>
	<b>2. Fuel mixture is too rich or too poor.</b> a. Possible damage to DPM. <i>If DPM does not operate properly, unplug compensation solenoid connector while engine is running. The carburetion is now identical to that of carburetors without a DPM, provided that all pipe fittings are tight and that solenoid is in good condition, (it must not be half-open). If problem is resolved with this procedure, DPM is faulty.</i>
	<b>3. Check for DPM manifold leaking.</b> a. DPM manifold is leaking. <i>Repair or replace.</i>

# TRANSMISSION AND BRAKE SYSTEMS

The following charts are provided to help diagnose the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

## TRANSMISSION

<b>SYMPTOM</b>	<b>THE SNOWMOBILE ACCELERATES SLOWLY, ESPECIALLY FROM A STANDING START.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check drive belt condition.</b></p> <p>a. Belt is too narrow (drive belt engagement is higher in drive pulley). <i>Replace belt if width is less than specified in DRIVE BELT.</i></p> <hr/> <p><b>2. Check distance between pulleys and/or drive belt deflection.</b></p> <p>a. Distance is too small between pulleys or deflection is too high (drive belt engagement is higher in drive pulley). <i>Distance between pulleys on REV is not adjustable. If incorrect, engine rubber mounts may be damaged, check and replace as required. Adjust drive belt height according to specifications (refer to PULLEY DISTANCE AND ALIGNMENT and DRIVE BELT).</i></p> <hr/> <p><b>3. Check if driven pulley sliding half slides freely.</b></p> <p>a. Jammed sliding half. <i>Replace.</i></p> <hr/> <p><b>4. Check spring tension of driven pulley sliding half.</b></p> <p>a. Sliding half rotation is accelerated when spring tension is too weak. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i></p> <hr/> <p><b>5. Refer to VIBRATIONS ORIGINATING FROM DRIVE PULLEY and VIBRATIONS ORIGINATING FROM DRIVEN PULLEY and check items listed.</b></p> <hr/> <p><b>6. Check drive pulley spring tension.</b></p> <p>a. Spring tension is too weak. <i>Replace.</i></p>

## Section 03 TROUBLESHOOTING

### Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

<b>SYMPTOM</b>	<b>ENGINE MAXIMUM RPM IS TOO HIGH AND TOP SPEED IS NOT REACHED.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check items 1, 2 and 3 of THE SNOWMOBILE ACCELERATES SLOWLY, ESPECIALLY FROM A STANDING START.</b>
	<b>2. Check driven pulley spring tension.</b> a. Spring tension is too stiff. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i>
	<b>3. Check position of the calibration screws (TRA drive pulley).</b> a. Selected numbers are too high. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i>
	<b>4. Refer to VIBRATIONS ORIGINATING FROM DRIVE PULLEY and check items listed.</b>
	<b>5. Check the driven pulley.</b> a. Driven pulley does not open completely. <i>Clean, readjust or replace driven pulley.</i>
	<b>6. Check if levers of drive pulley move freely.</b> a. Stuck levers. <i>Replace lever bushings.</i>

<b>SYMPTOM</b>	<b>LOOSE IN DRIVE SYSTEM WHEN ACCELERATING/DECELERATING.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check drive chain tension.</b> a. Drive chain is too loose. <i>Adjust.</i>
	<b>2. Check radial play of driven pulley.</b> a. Worn splines. <i>Replace pulley.</i>

**Section 03 TROUBLESHOOTING**  
Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

SYMPTOM	VIBRATIONS ORIGINATING FROM DRIVE PULLEY.
CONDITION	NORMAL USE.
TEST/INSPECTION	<p><b>1. Check drive belt.</b> a. Belt width is uneven on several places. <i>Replace.</i></p> <p><b>2. Check tightening torque of drive pulley screw.</b> a. Moving governor cup. <i>Retighten screw.</i></p> <p><b>3. Spring cover screws.</b> a. Spring cover moves and restrains sliding half movement. <i>Retighten screws.</i></p> <p><b>4. Check spring cover (TRA TYPE) and/or sliding half bushings.</b> a. Excessive gap between bushings and fixed half shaft, thus restraining sliding half movements. <i>Replace bushing(s).</i></p> <p><b>5. Check governor cup splines.</b> a. Excessive radial play. <i>Replace governor cup.</i></p> <p><b>6. Check lever assembly.</b> a. Lever assembly is damaged (worn bushing, bent lever etc.). <i>Replace damaged part.</i></p>


SYMPTOM	VIBRATIONS ORIGINATING FROM DRIVEN PULLEY.
CONDITION	NORMAL USE.
TEST/INSPECTION	<p><b>1. Check sliding half side play.</b> a. Sliding half bushing worn out. <i>Replace sliding half bushing.</i></p> <p><b>2. Check sliding half and fixed half straightness.</b> a. Sliding half/fixed half warped. <i>Replace.</i></p> <p><b>3. Check cam slider shoes.</b> a. One or two slider shoes out of three are broken. <i>Replace.</i></p>

## Section 03 TROUBLESHOOTING

### Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)


<b>SYMPTOM</b>	<b>PULLEYS DO NOT DOWN SHIFT PROPERLY.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check driven pulley spring tension.</b> a. Spring tension is too low. <i>Adjust according to specifications (refer to TECHNICAL DATA) or replace spring.</i>
	<b>2. Refer to VIBRATIONS COMING FROM DRIVEN PULLEY and check items listed.</b>
	<b>3. Check drive pulley bushings (cleanliness, wear, etc.).</b> a. Bushings stick to fixed half pulley shaft. <i>Clean or replace.</i>


<b>SYMPTOM</b>	<b>IN REVERSE ENGINE FAILS AND DRIVEN PULLEY OPENS TOO FAST (DRIVE BELT IS LOW IN DRIVEN PULLEY).</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check pulley distance and alignment.</b> a. Improper adjustment. <i>Adjust according to specifications (refer to PULLEY DISTANCE AND ALIGNMENT) and make sure that torque rod is resting against engine. Check engine mounts.</i>
	<b>2. Check for reverse sliding shoes.</b> a. Sliding shoes are worn or missing. <i>Replace sliding shoes.</i>
	<b>3. Check spring.</b> a. Spring is weak or insufficient tension. <i>Replace spring.</i>

<b>SYMPTOM</b>	<b>UNEVEN BELT WEAR ON ONE SIDE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>  	<b>1. Check tightening torque of engine mount bolts.</b> a. Loose engine mount. <i>Tighten mount nuts/bolts equally.</i>
	<b>2. Check pulley alignment.</b> a. Pulley misalignment. <i>Align pulleys.</i>
	<b>3. Check drive belt contact area on pulleys.</b> a. Rough or scratched pulley surfaces. <i>Repair or replace pulley half.</i>
	<b>4. Check driven pulley sliding half play.</b> a. Driven pulley bushing worn. <i>Replace bushing.</i>

A00D09Y


**Section 03 TROUBLESHOOTING**  
Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

<b>SYMPTOM</b>	<b>BELT GLAZED EXCESSIVELY OR HAVING BAKED APPEARANCE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<ol style="list-style-type: none"> <li><b>1. Check if drive pulley bushings are worn.</b> <ol style="list-style-type: none"> <li>a. Slipping due to insufficient pressure on belt sides. <i>Replace bushing.</i></li> </ol> </li> </ol>
 <p style="font-size: small;">A00D0AY</p>	<ol style="list-style-type: none"> <li><b>2. Check condition of drive pulley fixed half shaft.</b> <ol style="list-style-type: none"> <li>a. Slipping due to rusted drive or driven pulley shafts. <i>Clean shaft with fine steel wool.</i></li> </ol> </li> </ol>
	<ol style="list-style-type: none"> <li><b>3. Check if pulley halves are clean.</b> <ol style="list-style-type: none"> <li>a. Slipping due to oily pulley surfaces. <i>Clean pulley halves.</i></li> </ol> </li> </ol>
	<ol style="list-style-type: none"> <li><b>4. Check pulley calibration.</b> <ol style="list-style-type: none"> <li>a. Slipping due to improper pulley calibration. <i>Calibrate according to specifications.</i></li> </ol> </li> </ol>


<b>SYMPTOM</b>	<b>BELT WORN EXCESSIVELY IN TOP WIDTH.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<ol style="list-style-type: none"> <li><b>1. Check drive pulley.</b> <ol style="list-style-type: none"> <li>a. Excessive slippage due to jamming of drive pulley. <i>Inspect drive pulley.</i></li> </ol> </li> </ol>
 <p style="font-size: small;">A00D0BY</p>	<ol style="list-style-type: none"> <li><b>2. Check drive belt identification number.</b> <ol style="list-style-type: none"> <li>a. Improper belt angle (wrong type of belt). <i>Replace belt with an appropriate drive belt.</i></li> </ol> </li> </ol>
	<ol style="list-style-type: none"> <li><b>3. Check drive belt width.</b> <ol style="list-style-type: none"> <li>a. Considerable use. <i>Replace belt if less than specified in DRIVE BELT.</i></li> </ol> </li> </ol>

## Section 03 TROUBLESHOOTING

### Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)


<b>SYMPTOM</b>	<b>BELT TOO NARROW ON ONE SECTION.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>  	<b>1. Check for frozen track.</b> a. Frozen track. <i>Free track from ice.</i>
	<b>2. Check parking brake.</b> a. Parking brake is engaged. <i>Release parking brake.</i>
	<b>3. Check track tension/alignment.</b> a. Track too tight. <i>Adjust track tension and alignment.</i>
	<b>4. Check drive pulley.</b> a. Drive pulley does not operate properly. <i>Repair or replace drive pulley.</i>
	<b>5. Check idle speed.</b> a. Engine idle speed is too high. <i>Adjust according to specifications.</i>
	<b>6. Check drive belt length.</b> a. Incorrect belt length. <i>Replace with an appropriate drive belt (refer to TECHNICAL DATA).</i>
	<b>7. Check distance between pulleys.</b> a. Incorrect pulley distance. <i>Readjust according to specifications.</i>
	<b>8. Check belt height.</b> a. Belt height is incorrect. <i>Adjust according to specifications.</i>


A00D0CY


<b>SYMPTOM</b>	<b>BELT SIDES WORN CONCAVE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>  	<b>1. Check pulley half surfaces.</b> a. Rough or scratched pulley half surfaces. <i>Repair or replace.</i>
	<b>2. Check drive belt identification number.</b> a. Wrong belt. <i>Replace with an appropriate drive belt (refer to TECHNICAL DATA).</i>


A00D0DY

**Section 03 TROUBLESHOOTING**  
Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

<b>SYMPTOM</b>	<b>BELT DISINTEGRATION.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check drive belt identification number.</b></p> <p>a. Excessive belt speed. <i>Wrong type of belt. Replace with proper type of belt (refer to TECHNICAL DATA).</i></p>
 <small>A00D0EY</small>	<p><b>2. Check if pulley halves are clean.</b></p> <p>a. Oil on pulley surfaces. <i>Clean pulley surfaces with fine emery cloth and wipe clean using Pulley flange cleaner (P/N 413 711 809) and a cloth.</i></p>

<b>SYMPTOM</b>	<b>BELT CORD POP OUT.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check pulley alignment.</b></p> <p>a. Pulley misalignment. <i>Align pulley according to specifications (refer to TECHNICAL DATA).</i></p>
 <small>A00D0FY</small>	


<b>SYMPTOM</b>	<b>FATIGUE CRACKS BETWEEN COGS.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check drive belt condition.</b></p> <p>a. Belt considerably worn, worn out. <i>Replace.</i></p> <p>b. Distortion of natural belt shape due to improper storage. <i>Store properly.</i></p>
 <small>A00D0GY</small>	

<b>SYMPTOM</b>	<b>TOOTH CHUNK OUT.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check drive belt rotational direction.</b></p> <p>a. Improper belt installation. <i>Replace.</i></p>
 <small>A00D0HY</small>	<p><b>2. Check if drive belt rubs against components.</b></p> <p>a. Belt rubs against fixed components. <i>Relocate components.</i></p>
	<p><b>3. Check drive pulley.</b></p> <p>a. Violent engagement of drive pulley. <i>Check drive pulley engagement speed, drive pulley bushings and components.</i></p>



## Section 03 TROUBLESHOOTING

### Subsection 04 (TRANSMISSION AND BRAKE SYSTEMS)

<b>SYMPTOM</b>	<b>BELT "FLIP-OVER" AT HIGH SPEED.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check pulley alignment.</b> a. Pulley misalignment. <i>Align pulley according to specifications (refer to TECHNICAL DATA).</i>
 A00D01Y	<b>2. Check drive belt identification number.</b> a. Wrong type of belt. <i>Replace with an appropriate drive belt.</i>

## BRAKE SYSTEM

### HYDRAULIC BRAKE

<b>SYMPTOM</b>	<b>SPONGY BRAKE CONDITION.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Contaminated brake fluid.</b> <i>Replace brake fluid and bleed system. If the problem persists, replace master cylinder.</i>

<b>SYMPTOM</b>	<b>BRAKE FLUID LEAKAGE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check for loosen hose connectors.</b> <i>Replace copper washers and retighten.</i>
	<b>2. Check for damaged hose, master cylinder and caliper.</b> <i>Replace part(s) and check for proper mounting.</i>

<b>SYMPTOM</b>	<b>BRAKE SYSTEM IS NOISY.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check brake pad thickness.</b> a. Pads are worn out. <i>Replace.</i>
	<b>2. Check key/keyway.</b> a. Key/keyway is worn out. <i>Replace parts.</i>

# ELECTRICAL SYSTEM

The following chart is provided to help diagnose the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

SYMPTOM	STARTER DOES NOT TURN.
CONDITION	NORMAL USE.
TEST/INSPECTION	<b>1. Check 30 A and 5 A fuses.</b> a. Burnt fuse. <i>Check wiring condition and replace fuse.</i>
	<b>2. Check continuity of starter switch contact points.</b> a. Poor contact of starter switch contact points. <i>Repair or replace switch.</i>
	<b>3. Check continuity between starter switch and MPEM.</b> a. Open circuit. <i>Repair.</i>
	<b>4. Check continuity between MPEM and solenoid switch.</b> a. Open circuit. <i>Repair.</i>

SYMPTOM	STARTER TURNS BUT DOES NOT CRANK THE ENGINE.
CONDITION	NORMAL USE.
TEST/INSPECTION	<b>1. Check battery capacity.</b> a. Shorted battery cell(s). <i>Replace.</i>
	<b>2. Check battery charge.</b> a. Low battery. <i>Recharge battery and check recharge system and wires.</i>
	<b>3. Check wire connection.</b> a. Inadequate connection (too much resistance). <i>Clean and reconnect.</i>
	<b>4. Check brushes.</b> a. Poor contact of brushes. <i>Replace brushes.</i>
	<b>5. Check commutator.</b> a. Burnt commutator. <i>Machine commutator on a lathe. Respect outer diameter wear limit. Refer to ELECTRIC STARTER.</i>
	<b>6. Check engine.</b> a. Engine seized. <i>Overhaul the engine.</i>

## Section 03 TROUBLESHOOTING

### Subsection 05 (ELECTRICAL SYSTEM)

	<p><b>7. Check field coil resistance.</b></p> <p>a. Shorted field coil. <i>Repair or replace yoke.</i></p>
	<p><b>8. Check armature resistance.</b></p> <p>a. Shorted armature. <i>Repair or replace armature.</i></p>
	<p><b>9. Check tension of brush springs.</b></p> <p>a. Weak brush spring tension. <i>Replace springs.</i></p>
	<p><b>10. Check yoke assembly magnets.</b></p> <p>a. Weak magnets. <i>Replace yoke assembly.</i></p>
	<p><b>11. Check if bushings are worn.</b></p> <p>a. Worn bushings. <i>Replace bushings.</i></p>

<b>SYMPTOM</b>	<b>STARTER TURNS, BUT OVERRUNNING CLUTCH PINION DOES NOT MESH WITH RING GEAR.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check clutch pinion gear.</b></p> <p>a. Worn clutch pinion gear. <i>Replace clutch.</i></p>
	<p><b>2. Check clutch.</b></p> <p>a. Defective clutch. <i>Replace clutch.</i></p>
	<p><b>3. Check brackets.</b></p> <p>a. Worn or broken brackets. <i>Replace brackets.</i></p>
	<p><b>4. Check movement of clutch on splines.</b></p> <p>a. Poor movement of clutch on splines. <i>Clean and correct.</i></p>
	<p><b>5. Check clutch bushing.</b></p> <p>a. Worn clutch bushing. <i>Replace clutch.</i></p>
	<p><b>6. Check starter bushings.</b></p> <p>a. Worn starter bushing(s). <i>Replace bushing(s).</i></p>
	<p><b>7. Check ring gear.</b></p> <p>a. Worn ring gear. <i>Replace ring gear.</i></p>
	<p><b>8. Check for proper starter rotation direction.</b></p> <p>a. Starter turns in wrong direction, incorrectly installed brushes, wrong polarity or wrong starter. <i>Replace starter or reconnect properly.</i></p>

**Section 03 TROUBLESHOOTING**  
**Subsection 05 (ELECTRICAL SYSTEM)**

<b>SYMPTOM</b>	<b>ELECTRIC STARTER KEEPS TURNING WHEN ENGINE IS STARTED.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check clutch.</b></p> <p>a. Jammed clutch pinion gear. <i>Replace or clean.</i></p>
	<p><b>2. Check movement of clutch on splines.</b></p> <p>a. Clutch is stuck on splines. <i>Clean.</i></p>
	<p><b>3. Check starter brackets.</b></p> <p>a. Broken bracket(s). <i>Replace bracket(s).</i></p>
	<p><b>4. Check starter relay.</b></p> <p>a. Shorted starter relay winding(s). <i>Replace starter relay.</i></p>
	<p><b>5. Check starter relay contacts.</b></p> <p>a. Melted starter relay contacts. <i>Replace starter relay.</i></p>
	<p><b>6. Check starter relay.</b></p> <p>a. Starter relay returns poorly. <i>Replace starter relay.</i></p>

<b>SYMPTOM</b>	<b>NOISE OCCURENCE WHEN STARTING ENGINE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check if ring gear is well-mounted to drive pulley fixed half.</b></p> <p>a. Loose and/or broken bolts. <i>Retighten bolts using thread locker or replace ring gear and drive pulley fixed half.</i></p>

---


## Section 03 TROUBLESHOOTING

### Subsection 05 (ELECTRICAL SYSTEM)

---

<b>SYMPTOM</b>	<b>ELECTRIC STARTER SOMETIMES DOES NOT WORK WHEN ACTIVATED.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check battery cables and starter wires.</b> a. Corroded and/or loose connection(s). <i>Clean and/or retighten.</i>
	<b>2. Check 30 A and 5 A fuses.</b> a. Oxidized or burnt fuse. <i>Clean or replace.</i>
	<b>3. Check wiring harness connections.</b> a. Oxidized connections. <i>Clean or replace defective terminals.</i>
	<b>4. Check ignition switch.</b> a. Defective contacts in ignition switch. <i>Replace.</i>
	<b>5. Check solenoid of electric starter.</b> a. Shorted solenoid wiring harness or corroded contact washer. <i>Replace.</i>

**Section 03 TROUBLESHOOTING**  
**Subsection 05 (ELECTRICAL SYSTEM)**




A32E30S

**Section 03 TROUBLESHOOTING**  
**Subsection 05 (ELECTRICAL SYSTEM)**

**CHARGING SYSTEM DIAGNOSTIC FLOW CHART**

**360 W - 2 CYLINDER**

DC charging system all accessories are DC operated



A32E31S

**Section 03 TROUBLESHOOTING**  
Subsection 05 (ELECTRICAL SYSTEM)

<b>SYMPTOM</b>	<b>THE MPEM DOES NOT WORK.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check that high tension coil wires do not touch any metal parts.</b></p> <p>a. Short circuit. <i>Isolate and reroute wires.</i></p>

<b>SYMPTOM</b>	<b>ENGINE STALLS.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Refer to IGNITION SYSTEM DIAGNOSTIC FLOW CHART.</b>

<b>SYMPTOM</b>	<b>ENGINE IS MISFIRING — ERRATIC SPARK AT SPARK PLUG.</b>
<b>CONDITION</b>	RIDING ON WET SNOW.
<b>TEST/INSPECTION</b>	<p><b>1. Check if spark plug wires and/or spark plug cap seals are sealing out moisture.</b></p> <p>a. Defective wires and/or seals. <i>Replace defective part.</i></p> <p><b>2. Check if ignition system wiring harness connectors are in good condition and/or are sealing out moisture.</b></p> <p>a. Loose connectors, corroded terminals or defective parts. <i>Clean terminals and apply silicone dielectric grease. Replace defective parts.</i></p>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Verify misfiring by observing flash of stroboscopic timing light. Check condition of connectors.</b></p> <p>a. Defective spark plug(s) and/or cable(s)/cap(s). Defective electrical system wiring harness and/or accessories and/ignition cut-out switches. Condition of connector terminals. <i>Replace defective parts and/or repair damaged wires. Replace defective switch(es). Clean terminals and apply silicone dielectric grease.</i></p>
<b>CONDITION</b>	RIDING IN DEEP AND THICK SNOW.
<b>TEST/INSPECTION</b>	<p><b>1. Perform all verifications outlined under ENGINE DOES NOT START — NO SPARK AT SPARK PLUG.</b></p> <p><b>2. Check spark plugs. Proceed with spark plug analysis in order to identify source of problem.</b></p> <p>a. Defective and/or worn spark plug(s) and/or cable(s) and/or cap(s). Engine related problem. <i>Replace defective part(s). Proceed with ignition system testing procedures. Perform engine analysis.</i></p>



## Section 03 TROUBLESHOOTING

### Subsection 05 (ELECTRICAL SYSTEM)

<b>SYMPTOM</b>	<b>FOULED (BLACK) SPARK PLUG TIP.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check carburetor.</b> a. Carburetion is too rich. <i>Adjust according to specifications (refer to TECHNICAL DATA).</i>
	<b>2. Check if choke is partially open.</b> a. Choke is partially open. <i>Adjust according to specifications.</i>
	<b>3. Check injection oil consumption.</b> a. Injection pump flow is too high. <i>Adjust according to specifications or replace.</i>
	<b>4. Check oil quality.</b> a. Poor quality oil (creation of deposits). <i>Use BOMBARDIER injection oil.</i>
	<b>5. Check engine for leaks.</b> a. Leaking center seal on crankshaft. <i>Replace.</i>

<b>SYMPTOM</b>	<b>SPARK PLUG TIP IS LIGHT GRAY.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Refer to ENGINE SLOWS DOWN OR STOPS AT HIGH RPM and check items listed.</b>
	<b>2. Check spark plug heat range.</b> a. Spark plug heat range is too high. <i>Replace by Bombardier's recommended spark plug (refer to TECHNICAL DATA).</i>
	<b>3. Check if air intake silencer leaks.</b> a. Air surplus coming from opening(s) located between halves. <i>Seal.</i>
	<b>4. Check carburetor adapter collars.</b> a. Loose collar(s). <i>Tighten.</i>
	<b>5. Check carburetor adapter(s).</b> a. Cracked or deformed adapter(s). <i>Replace.</i>
	<b>6. Check if primary compression leaks.</b> a. Primary compression leaks. <i>Perform leak down test and repair as necessary.</i>

**Section 03 TROUBLESHOOTING**  
Subsection 05 (ELECTRICAL SYSTEM)

<b>SYMPTOM</b>	<b>RER (ROTAX ELECTRONIC REVERSE) DOES NOT WORK.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check idle speed.</b> a. Too low idle speed. <i>Adjust according to specification (refer to TECHNICAL DATA).</i>
	<b>2. Check spark plug.</b> a. Faulty spark plug. <i>Replace.</i>
	<b>3. Check drive belt height.</b> a. Wrong belt height. <i>Adjust according to specification (refer to DRIVE BELT).</i>
	<b>4. Check carburetor synchronization and air screw adjustment.</b> a. Wrong adjustment. <i>Adjust according to specification (refer to TECHNICAL DATA) and read CARBURETOR subsection.</i>
	<b>5. Check electrical connections.</b> a. Bad electrical connections or damaged wires. <i>Clean or replace.</i>
	<b>6. Check MPEM.</b> a. Faulty MPEM. <i>Replace.</i>
	<b>7. Check reverse trigger coil for proper resistance and harness continuity.</b> a. Faulty trigger coil. <i>Replace.</i>
<b>SYMPTOM</b>	<b>HEADLAMP NOT LIGHTING.</b>
<b>CONDITION</b>	WHITE BULB.
<b>TEST/INSPECTION</b>	<b>1. Check bulb.</b> a. Gas leak. <i>Replace bulb.</i>
<b>CONDITION</b>	BROKEN ELEMENT.
<b>TEST/INSPECTION</b>	<b>1. Check for loose headlamp housing and bulb socket.</b> a. Vibration problem. <i>Tighten headlamp mounting screws. Lock bulb in socket. Replace bulb.</i>
<b>CONDITION</b>	MELTED FILAMENT (ENDS OF ELEMENT HOLDER) AND BLACK BULB.
<b>TEST/INSPECTION</b>	<b>1. Check voltage at headlamp at different speeds. It must not be above 15 Vac.</b> <b>NOTE:</b> If quartz halogen bulb is involved, ensure that proper voltage regulator is installed. a. Excessive voltage in lighting circuit. <i>Replace voltage regulator and ensure proper grounding. Retest.</i>

## Section 03 TROUBLESHOOTING

### Subsection 05 (ELECTRICAL SYSTEM)

<b>SYMPTOM</b>	<b>HEADLAMP DIMING.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check voltage at headlamp at different speeds. It must not be below 11 Vac.</b></p> <p>a. Insufficient voltage in lighting circuit. <i>Replace voltage regulator and retest.</i></p> <p><b>2. Visually inspect wiring harness for damaged and/or melted wires and/or bad wire terminal crimping and/or connections.</b></p> <p>a. Heating, rotating or sharp part in contact with harness. Improper harness routing. <i>Repair/replace damaged wires and/or terminals. Reroute harness where necessary.</i></p> <p><b>3. Check if optional electric accessories are overloading the magneto/generator.</b></p> <p>a. Excessive electrical load to magneto/generator. <i>Reduce the electrical load by removing excess accessories. Reconnect as recommended by manufacturer.</i></p> <p><b>4. Hot Grips brand: Verify if they were connected in parallel by mistake.</b></p> <p>a. Excessive electrical load to magneto/generator. <i>Reconnect as recommended by manufacturer.</i></p> <p><b>5. Check if heating grips installation overloads the magneto capacity.</b></p> <p>a. Excessive electrical load to magneto/generator. <i>Reduce the electrical load by removing accessories.</i></p>

<b>SYMPTOM</b>	<b>FALSE FUEL AND/OR TEMPERATURE GAUGE READINGS.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Verify sender unit for free movement and/or correct arm position.</b></p> <p>a. Defective or damaged part. <i>Correct or replace sender unit.</i></p> <p><b>2. Verify sender unit/gauge wiring harness condition.</b></p> <p>a. Heating, rotating or sharp part in contact with harness. Improper harness routing. <i>Replace or repair damaged wires. Reroute where necessary.</i></p>

**Section 03 TROUBLESHOOTING**  
**Subsection 05 (ELECTRICAL SYSTEM)**

<b>SYMPTOM</b>	<b>NO ELECTRICAL ACCESSORIES WORK WHEN ENGINE IS ON IDLE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check idle speed.</b></p> <p>a. Too low idle speed. <i>Readjust to specifications.</i></p>
	<p><b>2. Verify regulator.</b></p> <p>a. Faulty regulator. <i>Replace.</i></p>
	<p><b>3. Check accessory relay.</b></p> <p>a. Relay contact does not close above 800 RPM because of defective wiring harness between MPEM and relay. <i>Repair.</i></p> <p>b. Relay contact does not close above 800 RPM because no signal is emitted by MPEM to activate the relay. <i>Replace MPEM.</i></p> <p>c. Relay found defective after testing it with a 12V battery. <i>Replace relay.</i></p>

<b>SYMPTOM</b>	<b>BRAKE LIGHT REMAINS ON.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check if bulb is properly installed.</b></p> <p>a. Bulb is not installed correctly (contact elements are reversed). <i>Install bulb correctly.</i></p>
	<p><b>2. Check brake switch.</b></p> <p>a. Switch contact remains closed. <i>Replace brake switch.</i></p>

## Section 03 TROUBLESHOOTING

### Subsection 05 (ELECTRICAL SYSTEM)

<b>SYMPTOM</b>	<b>REAR LIGHT BULB FLASHES.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check bulb tightness in housing.</b> a. Looseness at bulb contact elements. <i>Install bulb correctly.</i>
	<b>2. Check if rear light is properly connected.</b> a. Connector housing is partially connected. <i>Install connector housing properly.</i>
	<b>3. Check continuity of wires.</b> a. Corroded terminals and/or broken wires. <i>Replace terminal(s) or crimp defective wires.</i>
	<b>4. Check regulator.</b> a. Faulty regulator. <i>Replace.</i>

<b>SYMPTOM</b>	<b>TACHOMETER DOES NOT WORK.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check continuity of wires.</b> a. Corroded terminals and/or broken wires. <i>Replace terminal(s) or crimp defective wires.</i>
	<b>2. Check tachometer part number.</b> a. Models with 360 W magneto have a different tachometer. <i>Replace with appropriate one.</i>

# SUSPENSION AND TRACK

The following chart is provided to help diagnose the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

<b>SYMPTOM</b>	<b>SUSPENSION IS TOO LOW.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check condition of springs.</b></p> <p>a. Springs are broken. <i>Replace springs.</i></p>
	<p><b>2. Check springs preload.</b></p> <p>a. Low spring preload. <i>Increase preload to the recommended position.</i></p>
	<p><b>3. Check springs.</b></p> <p>a. Installed springs are too soft. <i>Install optional stiffer springs, refer to Service Bulletin SPRING REFERENCE ACCORDING TO LOAD.</i></p>

<b>SYMPTOM</b>	<b>REAR SUSPENSION BOTTOMS OUT.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check condition of springs.</b></p> <p>a. Springs are broken. <i>Replace springs.</i></p>
	<p><b>2. Check springs preload.</b></p> <p>a. Low spring preload. <i>Increase preload to the recommended position.</i></p>
	<p><b>3. Check springs.</b></p> <p>a. Springs installed are too soft. <i>Install optional stiffer springs, refer to Service Bulletin SPRING REFERENCE ACCORDING TO LOAD.</i></p>
	<p><b>4. Check the rear shock motion ratio position.</b></p> <p>a. It is adjusted in soft position. <i>Adjust rear shock motion ratio to firm position.</i></p>

## Section 03 TROUBLESHOOTING

### Subsection 06 (SUSPENSION AND TRACK)

<b>SYMPTOM</b>	<b>REAR SUSPENSION IS TOO STIFF.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check rear spring preload.</b> a. Too much preload. <i>Adjust to a softer position.</i>
	<b>2. Check springs.</b> a. Springs installed are too stiff. <i>Install optional softer springs, refer to Service Bulletin SPRING REFERENCE ACCORDING TO LOAD.</i>
	<b>3. Check the rear shock motion ratio position.</b> a. It is adjusted in firm position. <i>Adjust rear shock motion ratio to soft position.</i>
	<b>4. Check track tension.</b> a. Track is too tight. <i>Adjust.</i>
	<b>5. Check if axles are properly lubricated.</b> a. Improper lubrication and/or contaminated grease (sticky oil sludge). <i>Clean and/or lubricate.</i>

<b>SYMPTOM</b>	<b>WHEN HANDLEBAR IS TURNED, SNOWMOBILE UNDERSTEEERS.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check ski runner condition.</b> a. Worn ski runners. <i>Replace.</i>
	<b>2. Check ski spring preload.</b> a. Insufficient ski pressure on the ground. <i>Increase spring preload.</i>
	<b>3. Check if front arm stopper strap is too long.</b> a. Insufficient ski pressure on the ground. <i>Shorten stopper strap.</i>
	<b>4. Check front arm spring preload.</b> a. Insufficient ski pressure on the ground. <i>Loosen spring tension.</i>

**Section 03 TROUBLESHOOTING**  
Subsection 06 (SUSPENSION AND TRACK)

<b>SYMPTOM</b>	<b>HANDLEBAR IS DIFFICULT TO TURN.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check if the handle bar turns freely when skis are off the ground.</b></p> <ul style="list-style-type: none"> <li>a. Ball joints corrosion restrains movement. <i>Lubricate or replace the ball joint.</i></li> <li>b. Component need proper lubrication. <i>Lubricate. Refer to MAINTENANCE.</i></li> <li>c. Bent parts. <i>Replace parts.</i></li> </ul> <p><b>2. Check ski spring preload.</b></p> <ul style="list-style-type: none"> <li>a. Too much preload. <i>Reduce ski spring preload.</i></li> </ul> <p><b>3. Check position of stopper strap.</b></p> <ul style="list-style-type: none"> <li>a. Too much weight when stopper strap is short. <i>Lengthen front arm stopper strap.</i></li> </ul> <p><b>4. Check position of front arm spring adjustment cam(s).</b></p> <ul style="list-style-type: none"> <li>a. When spring tension is weak, more weight is transferred to the skis. <i>Increase spring preload.</i></li> </ul>

<b>SYMPTOM</b>	<b>THE SNOWMOBILE ZIGZAGS.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check ski runner condition.</b></p> <ul style="list-style-type: none"> <li>a. Worn or bent ski runners. <i>Replace ski runners.</i></li> </ul> <p><b>2. Check ski alignment.</b></p> <ul style="list-style-type: none"> <li>a. Improper ski alignment. <i>Align skis in order to obtain proper toe-out (opening) (to adjust, refer to STEERING SYSTEM).</i></li> </ul> <p><b>3. Check if bushings are too loose in steering system.</b></p> <ul style="list-style-type: none"> <li>a. Bushings are too loose. <i>Replace.</i></li> </ul> <p><b>4. Check ski pressure.</b></p> <ul style="list-style-type: none"> <li>a. Too much pressure on skis. <i>Reduce ski spring preload and/or increase center spring preload.</i></li> </ul>



## Section 03 TROUBLESHOOTING

### Subsection 06 (SUSPENSION AND TRACK)

<b>SYMPTOM</b>	<b>SLIDER SHOES WEAR OUT PREMATURELY/OR TRACK CLEATS BECOME BLUE.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check track tension.</b> a. Pressure is too great on slider shoes. <i>Adjust according to specifications (refer to TECHNICAL DATA). Replace defective parts.</i>
	<b>2. Check idler wheel condition.</b> a. Stuck bearing, flat spot on wheel or damaged wheel. <i>Replace defective parts.</i>
	<b>3. Check snow conditions or lack of snow.</b> a. Lack of lubrication of slider shoes. <i>Ask driver to ride in appropriate snow conditions (see Operator's Guide).</i>
	<b>4. Check slider shoes and/or suspension retaining screws.</b> a. Twisted slider shoes or loose retaining screws. <i>Replace defective parts and/or tighten loose screws.</i>
<b>SYMPTOM</b>	<b>DERAILING TRACK.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<b>1. Check track tension.</b> a. Track is too loose. <i>Adjust.</i>
	<b>2. Check if track and slider shoes are properly aligned.</b> a. Improper alignment. <i>Adjust.</i>

**Section 03 TROUBLESHOOTING**  
Subsection 06 (SUSPENSION AND TRACK)

<b>SYMPTOM</b>	<b>NOISE OR VIBRATION COMING FROM THE TRACK.</b>
<b>CONDITION</b>	NORMAL USE.
<b>TEST/INSPECTION</b>	<p><b>1. Check slide suspension retaining bolts.</b> a. Missing bolt(s) (some components interfere with track rotation). <i>Replace missing bolt(s).</i></p> <p><b>2. Check condition of idler wheel(s).</b> a. Idler wheel rubber is damaged. <i>Replace.</i></p> <p><b>3. Check guide cleats.</b> a. Top portion of guide cleat(s) is bent. <i>Replace.</i></p> <p><b>4. Check sprockets.</b> a. One or several teeth of drive shaft sprockets are broken. <i>Replace sprocket(s).</i></p> <p><b>5. Check track tension.</b> a. Track is too loose. <i>Adjust to recommended tension.</i></p> <p><b>6. Check track rods and/or internal traction teeth.</b> a. One or several track rods and/or teeth are broken. <i>Replace track.</i></p>