



WARNING: For safety reasons, this kit must be installed by an authorized Bombardier snow-mobile dealer. Should removal of a locking device be required when undergoing disassembly / assembly, always replace with a new one. This instruction sheet should be given to the purchaser. This kit is designed for specific applicable models only. It is not recommended for vehicles other than those for which it was sold.

NOTE: Installation time: Refer to Flat Rate Time Schedule Booklet, and proper model /model year.

PROCEDURE

Prior to installing new seat cover, remove all burrs and / or sharp edges, particularly on front corners of seat base. This will prevent reoccurring leatherette damage.