



◆ WARNING

For safety reasons, this kit must be installed by an authorized Bombardier snowmobile dealer. Should removal of a locking device be required when undergoing disassembly/assembly, always replace with a new one. This instruction sheet should be given to the purchaser. This kit is designed for specific applicable models only. It is not recommended for units other than those for which it was sold.

NOTE: Installation time is approximately 0.4 hour.

PARTS TO BE INSTALLED

The present kit consists of:

1. MPEM Assembly (1)
2. 6 mm (15/64 in) Tubing (426.7 mm (16.8 in))

INSTRUCTION

Refer to the *1998 Shop Manual Supplement*, (P/N 484 069 600) for procedure.

Cover BLACK ground cable with supplied tubing
no. 2.

Push tubing on BLACK ground cable until cable is completely covered; close each end of tubing with electrical tape to avoid tubing from starting to open after a while.