



ski-doo[®]
Snowmobiles

FLOORBOARD PAD KIT
P/N 860 702 300 (BLACK)
P/N 860 702 400 (RED)

◆ WARNING

For safety reasons, this kit must be installed by an authorized Bombardier snowmobile dealer. Should removal of a locking device be required when undergoing disassembly/assembly, always replace with a new one. This instruction sheet should be given to the purchaser. This kit is designed for specific applicable models only. It is not recommended for vehicles other than those for which it was sold.

NOTE: Installation time is approximately **0.5** hour.

PARTS TO BE INSTALLED

Kit consists of:

1. Left Floorboard Pad (1)
2. Right Floorboard Pad (1)

INSTRUCTION

It is recommended not to install floorboard pads in direct sunlight or in temperatures below 21°C (70°F).

Clean area; make sure surface is smooth and free from dirt and grease.

Prior removal of backing paper, place pads on floorboards to see how they fit.

If trimming should be required to properly fit pads, use a straight edge knife to cut material.

Peel off backing paper gradually while fitting pads; press firmly to assure proper adhesion.

Installation is now complete.

When required, pads can be cleaned using soap and a brush. Be sure to rinse thoroughly with water before using again.

860 702 300 ((BLACK/NOIR))

1.	520 000 119	Floorboard Pad (LH Side)	Tapis de marchepied (côté gauche)
2.	520 000 120	Floorboard Pad (RH Side)	Tapis de marchepied (côté droit)

860 702 400 (RED/ROUGE)

3.	520 000 121	Floorboard Pad (LH Side)	Tapis de marchepied (côté gauche)
4.	520 000 122	Floorboard Pad (RH Side)	Tapis de marchepied (côté droit)