



⚠ WARNING

For safety reasons, this kit must be installed by an authorized Ski-Doo® snowmobile dealer. Should removal of a locking device (e.g. lock tabs, self-locking fasteners, etc.) be required when undergoing disassembly/assembly, always replace with a new one. This instruction sheet should be given to the purchaser. This kit is designed for specific applicable models only. It is not recommended for units other than those for which it was sold.

NOTE: Installation time is approximately 0.5 hour.

PARTS TO BE INSTALLED

Kit, (not illustrated), consists of:

1. Mirror Assembly (RH) (P/N 517 302 067)
2. Mirror Assembly (LH) (P/N 517 302 068)

INSTRUCTIONS

Use template at the end of the present instruction sheet to locate and drill the two 5 mm (13/64 in) holes.

Remove flat washers and elastic stop nuts from underneath mirror assembly.

Install mirror and secure from underneath with flat washers and elastic stop nuts.

Repeat procedure for both sides.

THIS PAGE IS
PURPOSELY BLANK

TEMPLATE

CK3 SERIES

