


# WIRING DIAGRAM

## WIRING DIAGRAM LEGEND


**⚠ WARNING**

Ensure all terminals are properly crimped on the wires and all connector housings are properly fastened.



1. Wire colors
2. Housing area
3. Housing number per area
4. Wire connector location in housing

## WIRE COLORS AND CIRCUIT





The first color of a wire is the main color, second color is the stripe.

Example: YL/BK is a YELLOW wire with a BLACK stripe.

COLOR CODE					
BK	-	BLACK	PK	-	PINK
BL	-	BLUE	RD	-	RED
BR	-	BROWN	VI	-	VIOLET
GN	-	GREEN	WH	-	WHITE
GY	-	GREY	YL	-	YELLOW
OR	-	ORANGE			

## CONNECTOR HOUSING AREA




AREA	LOCATION
1	Front of engine compartment
2	Magneto
3	Carburetors
4	Near intake silencer
5	Near driven pulley
6	Under console
7	Under hood
8	Near fuel tank
9	Rear of seat
10	Under engine




























# Section 11 WIRING DIAGRAM

## Subsection 01 (WIRING DIAGRAM)

### CONNECTOR LOCATION IN HOUSING




**SYMBOLS DESCRIPTION**

<p>Beam and tail light</p> 	<p>Female terminal</p> 	<p>Male terminal</p> 	<p>Electronic module</p> 
<p>Meter</p> 	<p>Electric motor</p> 	<p>Low level sensor</p> 	<p>Buzzer</p> 
<p>Ignition coil</p> 	<p>Normally close switch</p> 	<p>Normally open switch</p> 	<p>Male terminal on instrument</p> 
<p>Engine ground</p> 	<p>Frame ground</p> 	<p>Spark plug</p> 	<p>Meter movement</p> 
<p>Bulb</p> 	<p>Pilot lamp</p> 	<p>Analog sensor</p> 	<p>Solenoid valve</p> 
<p>Magneto (Delta)</p> 	<p>3 position switch</p> 	<p>Heating element</p> 	<p>Fuse</p> 
<p>Trigger coil</p> 	<p>Battery</p> 		<p>Diode</p> 

A00E52S


# **ANNEX 1      MINI 2**

# MINI Z



POWER SUPPLY SYSTEM

IGNITION SWITCHES





ski-doo



**ski-doo**

©\*Trademarks of Bombardier Inc. and/or its subsidiaries.  
© 2000 Bombardier Inc. All rights reserved.  
Printed in Canada.

**BOMBARDIER**  
RECREATIONAL PRODUCTS



VERSION FRANÇAISE ÉGALEMENT DISPONIBLE