
SERVICE TOOLS

This is a list of tools to properly service Ski-Doo snowmobiles. The list includes both the mandatory tools included in a kit (P/N 861 743 700) and the optional tools that are ordered separately. The list of Service Products, both mandatory and optional, are not part of any kit and must all be ordered separately. If you need to replace or add to your tool inventory these items can be ordered through the regular parts channel.


Following mention points out new tool and product:

Subsection 01 (SERVICE TOOLS)

WORKSHOP — MANDATORY SERVICE TOOLS




ENGINE — MANDATORY SERVICE TOOLS



Subsection 01 (SERVICE TOOLS)

ENGINE (continued) — MANDATORY SERVICE TOOLS



Ceramic seal pusher (P/N 420 877 820)



A00B524

APPLICATION 494 and 670 engines with ceramic seal on water pump side.




APPLICATION All engines.


Fuel and oil system leak tester kit (P/N 529 033 100)




APPLICATION All models.




ENGINE (continued) — MANDATORY SERVICE TOOLS





APPLICATION All cageless bearing engines.






APPLICATION


A) 1994 and on rotary valve engines.B) Up to 1993 rotary valve engines.

Multimeter

(P/N 529 022 000)




APPLICATION All models.




NOTE: This tool replaces choke nut tool (P/N 529 032 200).

Subsection 01 (SERVICE TOOLS)

ENGINE (continued) — MANDATORY SERVICE TOOLS








ENGINE (continued) — RECOMMENDED SERVICE TOOLS


The following tools are highly recommended to optimize your basic tool kit and reduce repair time.



(P/N 420 940 755)
(P/N 420 840 681)
(P/N 420 841 201)
(P/N 420 976 890)
(P/N 420 876 552)
(P/N 420 876 557)
(P/N 420 977 490)
(P/N 420 977 475)
(P/N 420 276 025)
(P/N 420 977 494)
(P/N 420 977 479)

Subsection 01 (SERVICE TOOLS)


ENGINE (continued) — RECOMMENDED SERVICE TOOLS



All engines with Nippondenso CDI

(160 Ŵ).

ENGINE (continued) — RECOMMENDED SERVICE TOOLS




Subsection 01 (SERVICE TOOLS)

ENGINE (continued) — RECOMMENDED SERVICE TOOLS




B) Rotary valve engines with 12 mm

shaft.




ENGINE (continued) — RECOMMENDED SERVICE TOOLS




Subsection 01 (SERVICE TOOLS)

NGINE (continued) — RECOMMENDED SERVICE TOOLS




Subsection 01 (SERVICE TOOLS)

TRANSMISSION — MANDATORY SERVICE TOOLS




Subsection 01 (SERVICE TOOLS)

TRANSMISSION (continued) — MANDATORY SERVICE TOOLS



TRANSMISSION (continued) — MANDATORY SERVICE TOOLS



Subsection 01 (SERVICE TOOLS)

TRANSMISSION (continued) — RECOMMENDED SERVICE TOOLS


The following tools are highly recommended to optimize your basic tool kit and reduce repair time.






PRS chassis.

TRANSMISSION (continued) — RECOMMENDED SERVICE TOOLS



Subsection 01 (SERVICE TOOLS)

TRANSMISSION (continued) — RECOMMENDED SERVICE TOOLS



APPLICATION

All models except Tundra/R, Skandic WT/SWT/WT LC and S-Series with RER.


NOTE: Use this tool only with former puller (P/N 529 018 600) that has regular threads.



APPLICATION

All models except Tundra/R, Skandic WT/SWT/WT LC and S-Series with RER.

NOTE: Use this tool only with new puller (P/N 529 035 524) that has Acme threads and support plate included with extractor (P/N 529 031 100).




APPLICATION

S-Series with RER.


NOTE: Use this tool only with new puller (P/N 529 035 524) that has Acme threads and support plate included with extractor (P/N 529 031 100).

Large bushing installer and small bushing extractor (P/N 529 031 200)



APPLICATION

All models except Tundra/R, Skandic WT/SWT/WT LC and S-Series with RER.




TRANSMISSION (continued) — RECOMMENDED SERVICE TOOLS

TRA drive pulley puller (27 mm) (P/N 529 010 100)

A18B044

APPLICATION


TRA drive pulley (27 mm) shaft except 454, 670 and 779 engines.




Transmission adjuster (P/N 529 030 300)
A03D1T4
APPLICATION
Vehicles equipped with "push-pull shifter" reverse transmission.

Subsection 01 (SERVICE TOOLS)

SUSPENSION — MANDATORY SERVICE TOOLS




SUSPENSION (continued) — RECOMMENDED SERVICE TOOLS




Subsection 01 (SERVICE TOOLS)

SUSPENSION (continued) — RECOMMENDED SERVICE TOOLS




Subsection 01 (SERVICE TOOLS)

SUSPENSION (continued) — RECOMMENDED SERVICE TOOLS




Subsection 01 (SERVICE TOOLS)

VEHICLES — RECOMMENDED SERVICE TOOLS




VEHICLES (continued) — RECOMMENDED SERVICE TOOLS



Subsection 02 (SERVICE PRODUCTS)


SERVICE PRODUCTS


MANDATORY SERVICE PRODUCTS



Subsection 02 (SERVICE PRODUCTS)


MANDATORY SERVICE PRODUCTS (continued)






Subsection 02 (SERVICE PRODUCTS)


RECOMMENDED SERVICE PRODUCTS




Subsection 02 (SERVICE PRODUCTS)



Subsection 02 (SERVICE PRODUCTS)



Subsection 02 (SERVICE PRODUCTS)



Subsection 02 (SERVICE PRODUCTS)

